

Circutor

Power analyzer

CVM-C10




INSTRUCTION MANUAL


(M001B01-03-21A)




SAFETY PRECAUTIONS


Follow the warnings described in this manual with the symbols shown below.

| | |
|---|---|
|  | DANGER Warns of a risk, which could result in personal injury or material damage. |
|---|---|

| | |
|---|--|
|  | ATTENTION Indicates that special attention should be paid to a specific point. |
|---|--|

If you must handle the unit for its installation, start-up or maintenance, the following should be taken into consideration:

| | |
|---|--|
|  | <p>Incorrect handling or installation of the unit may result in injury to personnel as well as damage to the unit. In particular, handling with voltages applied may result in electric shock, which may cause death or serious injury to personnel. Defective installation or maintenance may also lead to the risk of fire.</p> <p>Read the manual carefully prior to connecting the unit. Follow all installation and maintenance instructions throughout the unit's working life. Pay special attention to the installation standards of the National Electrical Code.</p> |
|---|--|

| | |
|---|--|
|  | <p>Refer to the instruction manual before using the unit</p> <p>In this manual, if the instructions marked with this symbol are not respected or carried out correctly, it can result in injury or damage to the unit and / or installations.</p> |
|---|--|

CIRCUTOR, SA reserves the right to modify features or the product manual without prior notification.


DISCLAIMER

CIRCUTOR, SA reserves the right to make modifications to the device or the unit specifications set out in this instruction manual without prior notice.

CIRCUTOR, SA on its web site, supplies its customers with the latest versions of the device specifications and the most updated manuals.

www.circutor.com



| | |
|---|---|
|  | CIRCUTOR , recommends using the original cables and accessories that are supplied with the device. |
|---|---|

CONTENTS

| | |
|---|----|
| SAFETY PRECAUTIONS | 3 |
| DISCLAIMER | 3 |
| CONTENTS..... | 4 |
| REVISION LOG | 6 |
| 1.- VERIFICATION UPON RECEPTION | 7 |
| 2.- PRODUCT DESCRIPTION | 7 |
| 3.- DEVICE INSTALLATION | 9 |
| 3.1.- PRIOR RECOMMENDATIONS | 9 |
| 3.2.- INSTALLATION | 10 |
| 3.3.- CVM-C10-FLEX: ROGOWSKI SENSORS | 10 |
| 3.4.- DEVICE TERMINALS..... | 12 |
| 3.4.1.- LIST OF TERMINALS, CVM-C10-ITF, CVM-C10-MC AND CVM-C10-mV MODELS | 12 |
| 3.4.2.- LIST OF TERMINALS, CVM-C10-ITF-IN AND CVM-C10-MC-IN MODELS..... | 13 |
| 3.4.3.- LIST OF TERMINALS, CVM-C10-FLEX MODEL..... | 14 |
| 3.5.- CONNECTION DIAGRAM..... | 15 |
| 3.5.1.- MEASURING THREE-PHASE NETWORKS WITH A 4-WIRE CONNECTION, CVM-C10-ITF AND CVM-C10-mV MODEL..... | 15 |
| 3.5.2.- MEASURING THREE-PHASE NETWORKS WITH A 4-WIRE CONNECTION, CVM-C10-ITF-IN MODEL..... | 16 |
| 3.5.3.- MEASURING THREE-PHASE NETWORKS WITH A 4-WIRE CONNECTION CVM-C10-MC MODEL..... | 17 |
| 3.5.4.- MEASURING THREE-PHASE NETWORKS WITH A 4-WIRE CONNECTION CVM-C10-MC-IN MODEL..... | 18 |
| 3.5.5.- MEASURING THREE-PHASE NETWORKS WITH A 4-WIRE CONNECTION, CVM-C10-FLEX MODEL | 19 |
| 3.5.6.- MEASURING THREE-PHASE NETWORKS WITH A 3-WIRE CONNECTION, CVM-C10-ITF AND CVM-C10-mV MODEL. | 20 |
| 3.5.7.- MEASURING THREE-PHASE NETWORKS WITH A 3-WIRE CONNECTION, CVM-C10-MC MODEL. | 21 |
| 3.5.8.- MEASURING THREE-PHASE NETWORKS WITH A 3-WIRE CONNECTION, CVM-C10-FLEX MODEL..... | 22 |
| 3.5.9.- MEASURING THREE-PHASE NETWORKS WITH A 3-WIRE CONNECTION AND TRANSFORMERS WITH AN ARON CONNECTION, CVM-C10-ITF AND CVM-C10-MC MODELS. | 23 |
| 3.5.10.- MEASURING TWO-PHASE NETWORKS WITH A 3-WIRE CONNECTION, CVM-C10-ITF, CVM-C10-MC AND CVM-C10-mV MODELS..... | 24 |
| 3.5.11.- MEASURING TWO-PHASE NETWORKS WITH A 3-WIRE CONNECTION, CVM-C10-ITF-IN AND CVM-C10-MC-IN MODELS..... | 25 |
| 3.5.12.- MEASURING TWO-PHASE NETWORKS WITH A 3-WIRE CONNECTION, CVM-C10-FLEX MODEL..... | 26 |
| 3.5.13.- MEASURING SINGLE-PHASE NETWORKS, PHASE TO PHASE, WITH A 2-WIRE CONNECTION, CVM-C10-ITF, CVM-C10-MC AND CVM-C10-mV MODELS. | 27 |
| 3.5.14.- MEASURING SINGLE-PHASE NETWORKS, PHASE TO PHASE, WITH A 2-WIRE CONNECTION, CVM-C10-FLEX MODEL. | 28 |
| 3.5.15.- MEASURING SINGLE-PHASE NETWORKS, PHASE TO NEUTRAL, WITH A 2-WIRE CONNECTION, CVM-C10-ITF, CVM-C10-MC AND CVM-C10-mV MODELS. | 29 |
| 3.5.16.- MEASURING SINGLE-PHASE NETWORKS, PHASE TO NEUTRAL, WITH A 2-WIRE CONNECTION, CVM-C10-FLEX MODEL. | 30 |
| 4.- OPERATION..... | 31 |
| 4.1.- MEASURING PARAMETERS..... | 32 |
| 4.2.- KEYBOARD FUNCTIONS | 33 |
| 4.3.- DISPLAY | 35 |
| 4.3.1. $\cos \varphi$ - PF (POWER FACTOR) BAR | 35 |
| 4.3.2. ANALOGUE BAR | 36 |
| 4.3.3. OTHER SYMBOLS ON THE DISPLAY | 36 |
| 4.4.- LED INDICATORS..... | 37 |
| 4.5.- OPERATION PROFILES | 37 |
| 4.5.1. ANALYZER PROFILE..... | 37 |
| 4.5.2. e^3 PROFILE | 42 |
| 4.5.3. USER | 44 |
| 4.6.- HARMONICS..... | 44 |
| 4.7.- INPUTS..... | 45 |
| 4.8.- OUTPUTS..... | 45 |
| 4.9.- PROGRAMMING | 46 |
| 4.9.1. PRIMARY VOLTAGE | 47 |
| 4.9.2. SECONDARY VOLTAGE | 48 |
| 4.9.3. PRIMARY CURRENT | 48 |

| | |
|--|----|
| 4.9.4. SECONDARY CURRENT (MODEL CVM-C10-ITF) | 49 |
| 4.9.5. PRIMARY NEUTRAL CURRENT (MODELS: CVM-C10-ITF-IN AND CVM-C10-MC-IN) | 49 |
| 4.9.6. SECONDARY NEUTRAL CURRENT (MODEL CVM-C10-ITF-IN) | 50 |
| 4.9.7. NUMBER OF QUADRANTS | 50 |
| 4.9.8. MEASUREMENT CONVENTION | 50 |
| 4.9.9. TYPE OF INSTALLATION | 51 |
| 4.9.10. MAXIMUM DEMAND INTEGRATION PERIOD | 51 |
| 4.9.11. DELETING MAXIMUM DEMAND | 52 |
| 4.9.12. SELECTING THE OPERATION PROFILE | 52 |
| 4.9.13. BACKLIGHT, TURNING ON THE BACKLIT DISPLAY | 53 |
| 4.9.14. SELECTING THE $\cos \varphi$ - PF BAR ON THE DISPLAY | 54 |
| 4.9.15. DELETING MAXIMUM AND MINIMUM VALUES | 54 |
| 4.9.16. DELETING ENERGY VALUES | 54 |
| 4.9.17. SELECTING THE RANGE OF ENERGIES | 55 |
| 4.9.18. ACTIVATING THE HARMONICS DISPLAY SCREEN | 55 |
| 4.9.19. kgCO_2 CARBON EMISSION RATIO OF GENERATED ENERGY | 56 |
| 4.9.20. kgCO_2 CARBON EMISSION RATIO OF CONSUMED ENERGY | 56 |
| 4.9.21. COST RATIO OF GENERATED ENERGY | 57 |
| 4.9.22. COST RATIO OF CONSUMED ENERGY | 58 |
| 4.9.23. PROGRAMMING ALARM 1 (RELAY 1) | 58 |
| 4.9.24. PROGRAMMING ALARM 2 (RELAY 2) | 63 |
| 4.9.25. PROGRAMMING ALARM 3 (DIGITAL OUTPUT T1) | 63 |
| 4.9.26. PROGRAMMING ALARM 4 (DIGITAL OUTPUT T2) | 66 |
| 4.9.27. OPERATING MODE OF DIGITAL INPUT 1 | 66 |
| 4.9.28. OPERATING MODE OF DIGITAL INPUT 2 | 66 |
| 4.9.29. RS-485 COMMUNICATIONS: PROTOCOL | 67 |
| 4.9.30. LOCKING THE PROGRAMMING | 70 |
| 4.10.- COMMUNICATIONS | 72 |
| 4.10.1. CONNECTIONS | 72 |
| 4.10.2. PROTOCOL | 73 |
| 4.10.3. MODBUS COMMANDS | 74 |
| 4.10.4. BACnet PROTOCOL | 84 |
| 4.10.5. MAPA PICS | 85 |
| 5.- TECHNICAL FEATURES | 88 |
| 6.- MAINTENANCE AND TECHNICAL SERVICE | 92 |
| 7.- GUARANTEE | 92 |
| 8.- CE CERTIFICATE | 93 |

REVISION LOG

Table 1: Revision log.

| Date | Revision | Description |
|-------|----------------|--|
| 04/14 | M001B01-03-14A | Initial Version |
| 06/14 | M001B01-03-14B | Changes in the following sections: 3.4 - 4.9 - 4.10 - 5 |
| 06/14 | M001B01-03-14C | Changes in the following sections: 4.9.5 - 4.9.6 - 4.10.2.1 |
| 11/14 | M001B01-03-14D | Changes in the following sections: 4.9.21 - 4.9.23 - 4.10.2 - 4.10.3 - 5 |
| 11/14 | M001B01-03-14E | Changes in the following sections: 3.3.2 - 3.4.2 - 3.4.8 - 4.5 - 4.9 - 4.10.3.1 |
| 01/15 | M001B01-03-15A | Changes in the following sections: 2 - 3.3 - 3.4 - 4.1 - 4.9.4 - 4.9.28 - 4.10 - 4.10.3.2 - 5 |
| 10/15 | M001B01-03-15B | Changes in the following sections: 4.2 - 4.5.1 - 4.5.3 - 4.6 - 4.7 - 4.9 - 4.9.1 - 4.9.9 - 4.9.12 - 4.9.22 - 4.9.24 - 4.10.5 |
| 12/15 | M001B01-03-15C | Changes in the following sections: 3.2 - 4 - 4.3.1 - 4.9 - 4.10.3.6 - 4.10.4 - 4.10.5 - 5. |
| 07/16 | M001B01-03-16A | Changes in the following sections: 4.9.23 |
| 02/17 | M001B01-03-17A | Changes in the following sections: 2 - 3.3 - 3.4 - 3.5 - 4.7 - 4.8 - 4.9 - 4.10.3.6 - 4.10.3.7 - 5 |
| 07/17 | M001B01-03-17B | Changes in the following sections: 5 - 8. |
| 10/17 | M001B01-03-17C | Changes in the following sections: 3.3 - 5. |
| 06/18 | M001B01-03-18A | Changes in the following sections: 2 - 3.4.2 - 3.5 - 4.1 - 4.5.1 - 4.5.3 - 4.8 - 4.9.5 - 4.9.23 - 4.10.3.1 - 4.10.3.7.2 - 4.9.25 - 4.9.26 - 4.10.3.7.13 - 5. |
| 01/19 | M001B01-03-19A | Changes in the following sections: 3.3. |
| 02/19 | M001B01-03-19B | Changes in the following sections: 5. |
| 05/19 | M001B01-03-19C | Changes in the following sections: 4.5.1 - 4.10.3.7. |
| 10/19 | M001B01-03-19D | Changes in the following sections: 2 - 4.3 - 4.4. |
| 04/20 | M001B01-03-20A | Changes in the following sections: 4.10.3.3 - 5. |
| 05/21 | M001B01-03-21A | Changes in the following sections: 5. |

Note: Devices images are for illustrative purposes only and may differ from the actual device.

1.- VERIFICATION UPON RECEPTION

Check the following points when you receive the device:

- a) The device meets the specifications described in your order.
- b) The device has not suffered any damage during transport.
- c) Perform an external visual inspection of the device prior to switching it on.
- d) Check that it has been delivered with the following:
 - An installation guide,
 - 2 Retainers used to attach the device,
 - 5 connectors.



If any problem is noticed upon reception, immediately contact the transport company and/or **CIRCUTOR's** after-sales service.

2.- PRODUCT DESCRIPTION

The **CVM-C10** device measures, calculates and displays the main electrical parameters of the following networks: single-phase, two-phase, with and without neutral, balanced three-phase, with ARON measurements or unbalanced. The measurement will be taken in RMS with the three AC voltage inputs and three current inputs.

There are 6 versions of the device, depending on the type of current input:

- ✓ **CVM-C10-ITF**, indirect current measurement with /5A or /1A transformers.
- ✓ **CVM-C10-ITF-IN**, indirect current measurement with /5A or /1A transformers and an input to measure the neutral current.
- ✓ **CVM-C10-MC**, indirect current measurement with efficient transformers of the MC1 and MC3 series.
- ✓ **CVM-C10-MC-IN**, indirect current measurement with efficient transformers of the MC1 and MC3 series and an input to measure the neutral current.
- ✓ **CVM-C10-mV** indirect current measurement with /0.333V transformers.
- ✓ **CVM-C10-FLEX** current measurement through Rogowski sensors.



The device features:

- **3 keys** that allow you to browse between the various screens and program the device.
- **3 indicator LEDs**: CPU, ALARM and KEY.
- **LCD display**, displays all parameters,

- **2 digital inputs**, used to select the tariff or detect the logic state of external signals.
- **2 digital outputs**, fully programmable.
(Not available in the **CVM-C10-ITF-IN**, **CVM-C10-MC-IN** and **CVM-C10-FLEX** models)
- **2 alarm relays**, fully programmable (Not available in the **CVM-C10-FLEX** model)
- **RS-485** Communications, with two serial protocols: **MODBUS RTU**© and **BACnet**.

3.- DEVICE INSTALLATION

3.1.- PRIOR RECOMMENDATIONS



In order to use the device safely, it is critical that individuals who handle it follow the safety measures set out in the standards of the country where it is being used, use the necessary personal protective equipment, and pay attention to the various warnings indicated in this instruction manual.

The **CVM-C10** device must be installed by authorised and qualified staff.

The power supply plug must be disconnected and measuring systems switched off before handling, altering the connections or replacing the device. It is dangerous to handle the device while it is powered.

Also, it is critical to keep the cables in perfect condition in order to avoid accidents, personal injury and damage to installations.

The manufacturer of the device is not responsible for any damage resulting from failure by the user or installer to heed the warnings and/or recommendations set out in this manual, nor for damage resulting from the use of non-original products or accessories or those made by other manufacturers.

If an anomaly or malfunction is detected in the device, do not use it to take any measurements.

Inspect the work area before taking any measurements. Do not take measurements in dangerous areas or where there is a risk of explosion.



Disconnect the device from the power supply (device and measuring system power supply) before maintaining, repairing or handling the device's connections.
Please contact the after-sales service if you suspect that there is an operational fault in the device.

3.2.- INSTALLATION

The device will be installed on a panel ($92^{+0.8} \times 92^{+0.8}$ mm panel drill hole, in compliance with DIN 43700). All connections are located inside the electric panel.



Terminals, opening covers or removing elements can expose parts that are hazardous to the touch while the device is powered. Do not use the device until it is fully installed.

The device must be connected to a power circuit that is protected with gl (IEC 269) or M type fuses with a rating of 0.5 to 2 A. It must be fitted with a circuit breaker or equivalent device, in order to be able to disconnect the device from the power supply network.

The power and voltage measuring circuit must be connected with cables that have a minimum cross-section of 1mm^2 .

The secondary line of the current transformer will have a minimum cross-section of 2.5 mm^2 .

The temperature rating of insulation of wires connected to the device will be at minimum 62°C .

3.3.- CVM-C10-FLEX: ROGOWSKI SENSORS

The **CVM-C10-FLEX** model measures currents using flexible sensors, based on the Rogowski coil principle.

The flexibility of the sensor allows it to measure an alternating current irrespective of the position of the conductor.

CIRCUTOR has a Rogowski sensor model that can be used with the **CVM-C10-FLEX: FLEX-MAG**.


Table 3 shows the connection of the sensors and **Table 2** the maximum position error.

Note: For more information, consult the corresponding sensor guide.

Table 2: Position error.

| Position | Error |
|----------|-------------|
| | $\pm 1\%$ |
| | $A \pm 3\%$ |

Table 3: Probe cable terminal connections

| Probe cable terminal connections | |
|--|---|
| FLEX-MAG | |
|  | |
| | <p>Black : Shield (SHLD) Blue: Common (C) Green: Measuring channel (L1, L2, L3, N)</p> |

3.4.- DEVICE TERMINALS

3.4.1.- LIST OF TERMINALS, CVM-C10-ITF, CVM-C10-MC AND CVM-C10-mV MODELS

Table 4: List of terminals of the CVM-C10-ITF, CVM-C10-MC and CVM-C10-mV.

| Device terminals | |
|--|--|
| 1 : A1 Auxiliary power supply. | 13: I2, digital input 2 / tariff selection |
| 2: A2 Auxiliary power supply. | 14: V _{L1} , Voltage input L1 |
| 3: Rc, Common relay output | 15: V _{L2} , Voltage input L2 |
| 4: R2, Relay output 2 | 16: V _{L3} , Voltage input L3 |
| 5: R1, Relay output 1 | 17: N, Neutral |
| 6: CT, Common digital output. | 18: S1, Current input L1 |
| 7: T2, Digital output 2 | 19: S2, Current input L1 |
| 8: T1, Digital output 1 | 20: S1, Current input L2 |
| 9: A(+), RS485 | 21: S2, Current input L2 |
| 10: B(-), RS485 | 22: S1, Current input L3 |
| 11: GND, for RS485 and digital inputs | 23: S ₂ , Current input L3 |
| 12: I1, digital input 1 / tariff selection | |




Figure 1: Terminals of the CVM-C10-ITF, CVM-C10-MC and CVM-C10-mV.

3.4.2.- LIST OF TERMINALS, CVM-C10-ITF-IN AND CVM-C10-MC-IN MODELS.

Table 5: List of terminals of the CVM-C10-ITF-IN and CVM-C10-MC-IN.

| Device terminals | |
|--|--|
| 1: A1 Auxiliary power supply. | 12: I2, digital input 2 / tariff selection |
| 2: A2 Auxiliary power supply. | 13: V _{L1} , Voltage input L1 |
| 3: Rc, Common relay output | 14: V _{L2} , Voltage input L2 |
| 4: R2, Relay output 2 | 15: V _{L3} , Voltage input L3 |
| 5: R1, Relay output 1 | 16: N, Neutral |
| 6: S2, Neutral current input | 17: S1, Current input L1 |
| 7: S1, Neutral current input | 18: S2, Current input L1 |
| 8: A(+), RS485 | 19: S1, Current input L2 |
| 9: B(-), RS485 | 20: S2, Current input L2 |
| 10: GND, for RS485 and digital inputs | 21: S1, Current input L3 |
| 11: I1, digital input 1 / tariff selection | 22: S2, Current input L3 |




Figure 2: Terminals of the CVM-C10-ITF-IN and CVM-C10-MC-IN.

3.4.3.- LIST OF TERMINALS, CVM-C10-FLEX MODEL

Table 6: List of terminals of the CVM-C10-FLEX.

| Device terminals | |
|--|----------------------------------|
| 1 : A1 Auxiliary power supply. | 10: V_{L3} , Voltage input L3 |
| 2: A2 Auxiliary power supply. | 11: N, Neutral |
| 3: A(+), RS485 | 12: L1, Current input L1 |
| 4: B(-), RS485 | 13: L2, Current input L2 |
| 5: GND, for RS485 and digital inputs. | 14: L3, Current input L3 |
| 6: I1, digital input 1 / selection rate. | 15: LN, Current input LN |
| 7: I2, digital input 2 / selection rate. | 16: C, Common for current inputs |
| 8: V_{L1} , Voltage input L1 | 17: SHLD, GND for current inputs |
| 9: V_{L2} , Voltage input L2 | |




Figure 3:Terminals of the CVM-C10-FLEX.

3.5.- CONNECTION DIAGRAM

3.5.1.- MEASURING THREE-PHASE NETWORKS WITH A 4-WIRE CONNECTION, CVM-C10-ITF AND CVM-C10-mV MODEL.


Measurement system: **4-3Ph**

Figure 4: Three-Phase measuring with a 4-wire connection, CVM-C10-ITF and CVM-C10-mV model.

3.5.2.- MEASURING THREE-PHASE NETWORKS WITH A 4-WIRE CONNECTION, CVM-C10-ITF-IN MODEL.

Measurement system: **4-3Ph**




Figure 5: Three-Phase Measuring with a 4-wire connection, CVM-C10-ITF-IN model.

3.5.3.- MEASURING THREE-PHASE NETWORKS WITH A 4-WIRE CONNECTION CVM-C10-MC MODEL.


Measurement system: **4-3Ph**


Figure 6: Three-Phase measuring with a 4-wire connection, CVM-C10-MC model.

Note: Do not connect MC current transformers to ground.




The MC transformer secondary value is set to 0.250 A (fixed value)

Measurement system: **4-3Ph**



Note: Do not connect MC current transformers to ground.



3.5.5.- MEASURING THREE-PHASE NETWORKS WITH A 4-WIRE CONNECTION, CVM-C10-FLEX MODEL

Measurement system: **4-3Ph**




Figure 8: Three-Phase measuring with a 4-wire connection, CVM-C10-FLEX model.



It is mandatory connect the **SHLD** terminal of the probe.

3.5.6.- MEASURING THREE-PHASE NETWORKS WITH A 3-WIRE CONNECTION, CVM-C10-ITF AND CVM-C10-mV MODEL.

Measurement system: **3-3Ph**




Figure 9: Three-Phase measuring with a 3-wire connection, CVM-C10-ITF and CVM-C10-mV model.

3.5.7.- MEASURING THREE-PHASE NETWORKS WITH A 3-WIRE CONNECTION, CVM-C10-MC MODEL.


Measurement system: **3-3Ph**

Figure 10: Three-Phase measuring with a 3-wire connection, CVM-C10-MC model.

Note: Do not connect MC current transformers to ground.



The MC transformer secondary value is set to 0.250 A (fixed value)

3.5.8.- MEASURING THREE-PHASE NETWORKS WITH A 3-WIRE CONNECTION, CVM-C10-FLEX MODEL.

Measurement system: **3-3Ph**




Figure 11: Three-Phase measuring with a 3-wire connection, CVM-C10-FLEX model.



It is mandatory connect the **SHLD** terminal of the probe.

3.5.9.- MEASURING THREE-PHASE NETWORKS WITH A 3-WIRE CONNECTION AND TRANSFORMERS WITH AN ARON CONNECTION, CVM-C10-ITF AND CVM-C10-MC MODELS.

Measurement system: **3-ARON**




Figure 12: Three-Phase measuring with a 3-wire connection and transformers with an ARON connection, CVM-C10-ITF and CVM-C10-MC and models.

⁽¹⁾**Note:** Do not connect MC current transformers to ground.



CVM-C10-ITF model:

The transformer secondary value must be 5A or 1A

CVM-C10-MC model:

The MC transformer secondary value is set to 0.250 A (fixed value)

3.5.10.- MEASURING TWO-PHASE NETWORKS WITH A 3-WIRE CONNECTION, CVM-C10-ITF, CVM-C10-MC AND CVM-C10-mV MODELS.

Measurement system: **3-2Ph**




Figure 13: Measuring Two-Phase Networks with a 3-wire connection, CVM-C10-ITF, CVM-C10-MC and CVM-C10-mV models.

⁽¹⁾ **Note:** Do not connect MC current transformers to ground.



CVM-C10-ITF model:

The transformer secondary value must be 5A or 1A

CVM-C10-MC model:

The MC transformer secondary value is set to 0.250 A (fixed value)

CVM-C10-mV model:

The transformer secondary value must be 0.333 V

3.5.11.- MEASURING TWO-PHASE NETWORKS WITH A 3-WIRE CONNECTION, CVM-C10-ITF-IN AND CVM-C10-MC-IN MODELS.

Measurement system: **3-2Ph**




Figure 14: Measuring Two-Phase Networks with a 3-wire connection, CVM-C10-ITF-IN and CVM-C10-MC-IN models.

⁽¹⁾ **Note:** Do not connect MC current transformers to ground.



CVM-C10-ITF-IN model:

The transformer secondary value must be 5A or 1A

CVM-C10-MC-IN model:

The MC transformer secondary value is set to 0.250 A (fixed value)

3.5.12.- MEASURING TWO-PHASE NETWORKS WITH A 3-WIRE CONNECTION, CVM-C10-FLEX MODEL.

Measurement system: **3-2Ph**




Figure 15: Measuring Two-Phase Networks with a 3-wire connection, CVM-C10-FLEX model.



It is mandatory connect the **SHLD** terminal of the probe.

3.5.13.- MEASURING SINGLE-PHASE NETWORKS, PHASE TO PHASE, WITH A 2-WIRE CONNECTION, CVM-C10-ITF, CVM-C10-MC AND CVM-C10-mV MODELS.

Measurement system: **2-2Ph**




Figure 16: Measuring Single-Phase Networks, phase to phase, with a 2-wire connection, CVM-C10-ITF, CVM-C10-MC and CVM-C10-mV models.

⁽¹⁾**Note:** Do not connect MC current transformers to ground.



CVM-C10-ITF model:

The transformer secondary value must be 5A or 1A

CVM-C10-MC model:

The MC transformer secondary value is set to 0.250 A (fixed value)

CVM-C10-mV model:

The transformer secondary value must be 0.333 V

3.5.14.- MEASURING SINGLE-PHASE NETWORKS, PHASE TO PHASE, WITH A 2-WIRE CONNECTION, CVM-C10-FLEX MODEL.

Measurement system: **2-2Ph**




Figure 17: Measuring Single-Phase Networks, phase to phase, with a 2-wire connection, CVM-C10-FLEX model.



It is mandatory connect the **SHLD** terminal of the probe.

3.5.15.- MEASURING SINGLE-PHASE NETWORKS, PHASE TO NEUTRAL, WITH A 2-WIRE CONNECTION, CVM-C10-ITF, CVM-C10-MC AND CVM-C10-mV MODELS.

Measurement system: **2 - 1Ph**




Figure 18: Measuring Single-Phase Networks, phase to neutral, with a 2-wire connection, CVM-C10-ITF, CVM-C10-MC and CVM-C10-mV models.

⁽¹⁾ **Note:** Do not connect MC current transformers to ground.



CVM-C10-ITF model:

The transformer secondary value must be 5A or 1A

CVM-C10-MC model:

The MC transformer secondary value is set to 0.250 A (fixed value)

CVM-C10-mV model:

The transformer secondary value must be 0.333 V

3.5.16.- MEASURING SINGLE-PHASE NETWORKS, PHASE TO NEUTRAL, WITH A 2-WIRE CONNECTION, CVM-C10-FLEX MODEL.

Measurement system: **2 - 1Ph**




Figure 19: Measuring Single-Phase Networks, phase to neutral, with a 2-wire connection, CVM-C10-FLEX model.



It is mandatory connect the **SHLD** terminal of the probe.

4.- OPERATION

The **CVM-C10** is a four-quadrant power analyzer (consumption and generation).
The device can operate according to three different measurement conventions:

- ✓ **CIRCUTOR** measurement convention.
- ✓ **IEC** measurement convention.
- ✓ **IEEE** measurement convention.

The measurement convention is configured in the setup menu, see "**4.9.8. Measurement convention**".

- ✓ **CIRCUTOR** measurement convention





Figure 20: CIRCUTOR measurement convention.

- ✓ **IEC** measurement convention

Operation in the 4 quadrants (Q1, Q2, Q3, Q4)



$\cos \varphi$ values in the receiver operating mode (Q1, Q4)




Figure 21: Convenio de medida IEC.

✓ IEEE measurement convention




Figure 22: Convenio de medida IEEE.

4.1.- MEASURING PARAMETERS

The device displays the electrical parameters shown in Table 7.

Table 7: Measuring parameters of the CVM-C10.

| Parameter | Units | Phases L1-L2-L3 | Total III | N |
|---|--------------------|--------------------|--------------|---|
| Phase-neutral voltage | V _{ph-N} | ✓ | | |
| Phase-phase voltage | V _{ph-ph} | ✓ | ✓ | |
| Current | A | ✓ | ✓ | ✓ |
| Frequency | Hz | ✓ | ✓ | |
| Active power | M/kW | ✓ | ✓ | |
| Apparent power | M/kVA | ✓ | ✓ | |
| Total Reactive Power | M/kvar | ✓ | ✓ | |
| Total Reactive Power - Consumption | M/kvar | ✓ | ✓ | |
| Total Reactive Power - Generation | M/kvar | ✓ | ✓ | |
| Total Inductive Reactive Power | M/kvarL | ✓ | ✓ | |
| Inductive Reactive Power - Consumption | M/kvarL | ✓ | ✓ | |
| Inductive Reactive Power - Generation | M/kvarL | ✓ | ✓ | |
| Total Capacitive Reactive Power | M/kvarC | ✓ | ✓ | |
| Capacitive Reactive Power - Consumption | M/kvarC | ✓ | ✓ | |
| Capacitive Reactive Power - Generation | M/kvarC | ✓ | ✓ | |
| Power factor | PF | ✓ | ✓ | |
| Cos φ | φ | ✓ | ✓ | |
| THD % Voltage | % THD V | ✓ | | |
| THD % Current | % THD A | ✓ | | |
| Harmonic Breakdown - Voltage (up to the 31st order harmonic) | harm V | ✓ | | |

Table 7 (Continuation): Measuring parameters of the CVM-C10.

| Parameter | Units | Phases L1-L2-L3 | Total III | N |
|---|-------------------|--------------------|--------------|-------|
| Harmonic Breakdown - Current (up to the 31st order harmonic) | harm V | ✓ | | |
| Total Active Energy | M/kWh | | ✓ | |
| Total Inductive Reactive Energy | M/kvarLh | | ✓ | |
| Total Capacitive Reactive Energy | M/kvarCh | | ✓ | |
| Total Apparent Energy | M/kVAh | | ✓ | |
| Active Energy Tariff 1 | M/kWh | | ✓ | |
| Inductive Reactive Energy Tariff 1 | M/kvarLh | | ✓ | |
| Capacitive Reactive Energy Tariff 1 | M/kvarCh | | ✓ | |
| Apparent Energy Tariff 1 | M/kVAh | | ✓ | |
| Active Energy Tariff 2 | M/kWh | | ✓ | |
| Inductive Reactive Energy Tariff 2 | M/kvarLh | | ✓ | |
| Capacitive Reactive Energy Tariff 2 | M/kvarCh | | ✓ | |
| Apparent Energy Tariff 2 | M/kVAh | | ✓ | |
| Active Energy Tariff 3 | M/kWh | | ✓ | |
| Inductive Reactive Energy Tariff 3 | M/kvarLh | | ✓ | |
| Capacitive Reactive Energy Tariff 3 | M/kvarCh | | ✓ | |
| Apparent Energy Tariff 3 | M/kVAh | | ✓ | |
| Maximum Current Demand | A | ✓ | ✓ | |
| Maximum Demand of Active power | M/kW | | ✓ | |
| Maximum Demand of Apparent Power | M/kVA | | ✓ | |
| Maximum Demand of inductive Reactive Power | M/kvarLh | | ✓ | |
| Maximum Demand of capacitive Reactive Power | M/kvarCh | | ✓ | |
| Parameter | Units | Tariff: T1-T2-T3 | | Total |
| No. of hours | hours | ✓ | | ✓ |
| Cost | COST | ✓ | | ✓ |
| CO ₂ Emissions | kgCO ₂ | ✓ | | ✓ |

4.2.- KEYBOARD FUNCTIONS

The **CVM-C10** has 3 keys that allow you to browse between the various screens and program the device.

Key functions on measuring screens (**Table 8**):

Table 8: Key functions on measuring screens.













| Key | Short keystroke | Long keystroke (2 s) |
|---|-----------------|--------------------------|
|  | Previous screen | Display of minimum value |
|  | Next screen | Display of maximum value |

Table 8 (Continuation): Key functions on measuring screens.

| Key | Short keystroke | Long keystroke (2 s) |
|---|--|--------------------------------|
|  | Browsing the different profiles (analyzer, user, e3) | Accessing the programming menu |
|   | | Display of the Maximum Demand |
|   | | Active alarm information |
|   | | Unlocks the active alarm |




Key functions on harmonics screens (Table 9):

Table 9: Key functions on harmonics screens.

| Key | Short keystroke | Long keystroke (2 s) |
|--|---|--------------------------------|
|  | Output of the harmonics screens | |
|  | Next screen | |
|  | Browsing the different types of harmonics | Accessing the programming menu |




Key functions on the programming menu, query mode (Table 10):

Table 10: Key functions on the programming menu, query mode.

| Key | Short keystroke | Long keystroke (2 s) |
|---|-----------------|---|
|  | Previous screen | Programming output |
|  | Next screen | Programming output |
|  | | Opening the programming menu in the edit mode |

Key functions on the programming menu, edit mode (Table 11):

Table 11: Key functions on the programming menu, edit mode.

| Key | Keystroke |
|---|--|
|  | Line jump. |
|  | Increases the digits (0-9) or rotates between the different options. |
|  | Moves an editable digit (flashing) |

4.3.- DISPLAY

The device has a backlit LCD display showing all the parameters listed in Table 3. The display is divided into four areas (Figure 23):




Figure 23: CVM-C10 Display areas

✓ The area with **data per phase** displays the instantaneous, maximum and minimum values of each phase being measured or calculated by the device.

✓ The **total data** area displays the totals of the values being measured or calculated by the device.

✓ **Analogue bar**, displays the % of the current power of the installation.

✓ **Cos ϕ - PF Bar**, displays the value of the system's Cos ϕ or power factor in real time.

4.3.1. cos ϕ - PF (POWER FACTOR) BAR



Figure 24: Cos ϕ - PF Bar

This bar displays the value of the installation's cos ϕ or power factor in real time.

The parameter that will be displayed is selected on the programming menu. ("4.9.14. *Selecting the Cos ϕ - PF bar on the display*")

Note: This bar will not be displayed in the IEC and IEEE measurement conventions.

4.3.2. ANALOGUE BAR




Figure 25: Analogue Bar

The analogue bar displays two parameters:

✓ **Current power of the installation in %**

This parameter is displayed in 12 divisions, each one represents 10%, into which the analogue bar is divided.

The device calculates the current power of the installation using the formula:

$$P = V \cdot I \cdot \cos(\varphi)$$

Where the voltage and the $\cos(\varphi)$ are the installation's current values.

The current is referenced in its full scale. (100% is the full scale of the device and a value above 100% indicates that it is out of range).

✓ **The maximum system demand reached**, i.e., the maximum power value reached since the device was started, expressed as a percentage.

This value is displayed with the icon ◀.

The value and the maximum and minimum values are reset. ("**4.9.15. Deleting maximum and minimum values**")

Example: Figure 25 shows that the installation performance is 50% and that the maximum demand of the system is 80%.

4.3.3. OTHER SYMBOLS ON THE DISPLAY

The following are also shown on the display:

✓ **Type of installation**

The type of installation to which the device is connected can be selected on the programming menu, ("**4.9.9. Type of installation**"). The selected type is shown on the top left of the display.

✓ **State of digital inputs**

If the digital inputs have been activated, the top left of the display will show the icons **I1 I2** that indicate that the digital input is active.

4.4.- LED INDICATORS

The **CVM-C10** device has 3 LEDs:

- **CPU**, indicates that the device is on, flashing each second.
- **ALARM**, indicates that an alarm has been activated if it is on
- **KEY**, LED that is lit when any key is pressed.




Figure 26: LED Indicators of the CVM-C10.

4.5.- OPERATION PROFILES

The **CVM-C10** has 3 operation profiles. The display screens will be opened for the corresponding profile:

- ✓ Analyzer profile, **analyzer**,
- ✓ Electrical energy efficiency profile, **e³**,
- ✓ User profile, **user**,

4.5.1. ANALYZER PROFILE

This profile is identified with the **analyzer** symbol on the bottom of the screen (Figure 27)








Figure 27: CVM-C10 screen with the analyzer profile.

The device displays 11 different screens for the **analyzer** profile (Table 12) and the voltage and current harmonics, up to the 31st order harmonic, for each one of the lines, L1, L2 and L3. ("4.6.- HARMONICS")

Use keys  and  to browse the different screens.

The **inst** symbol on the bottom of the screen indicates that the values being displayed are of the instantaneous type.

Table 12: Analyzer profile screens.

| Screen | Parameters (units) |
|---|--|
|  | phase-phase Voltage L1-L2 (V_{ph-ph}) phase-phase Voltage L2-L3 (V_{ph-ph}) phase-phase Voltage L3-L1 (V_{ph-ph}) Frequency (Hz) |
|  | phase-neutral Voltage L1 (V_{ph-N}) phase-neutral Voltage L2 (V_{ph-N}) phase-neutral Voltage L3 (V_{ph-N}) Frequency (Hz) |
|  | Current L1 (A) Current L2 (A) Current L3 (A) Neutral Current (A) ⁽²⁾ |
|  | Active Power L1 (M/K W) Active Power L2 (M/K W) Active Power L3 (M/K W) Active Power III (M/K W) <i>The generation values are not measured when the 2 quadrant option is selected.</i> |

⁽²⁾ Not available for the 3-3Ph and 3-Ar-0N installation types.

Table 12 (Continuation): Analyzer profile screens.









| Screen | Parameters (units) |
|---|--|
|  | <p>Apparent Power L1 (M/KVA) Apparent Power L2 (M/KVA) Apparent Power L3 (M/KVA) Apparent Power III (M/KVA)</p> <p><i>The generation values are not measured when the 2 quadrant option is selected.</i></p> |
|  | <p>Inductive Reactive Power L1 (M/Kvar^L) Inductive Reactive Power L2 (M/Kvar^L) Inductive Reactive Power L3 (M/Kvar^L) Inductive Reactive Power III (M/Kvar^L)</p> |
|  | <p>Capacitive Reactive Power L1 (M/Kvar_C) Capacitive Reactive Power L2 (M/Kvar_C) Capacitive Reactive Power L3 (M/Kvar_C) Capacitive Reactive Power III (M/Kvar_C)</p> |
|  | <p>THD % Voltage L1 (V THD %) THD % Voltage L2 (V THD %) THD % Voltage L3 (V THD %)</p> |
|  | <p>THD % Current L1 (A THD %) THD % Current L2 (A THD %) THD % Current L3 (A THD %)</p> |

Table 12 (Continuation): Analyzer profile screens.

| Screen | Parameters (units) |
|---|---|
|  | Power factor L1 (PF) Power factor L2 (PF) Power factor L3 (PF) Power factor III (PF) |
|  | Cos φ L1 (cos φ) Cos φ L2 (cos φ) Cos φ L3 (cos φ) Cos φ III (cos φ) |

Also displayed on these screens are:

✓ **Maximum values**

To see the maximum values of the screen being displayed, press the  key for 2 seconds. These are displayed for 30 seconds. The **max** symbol is shown on the display (Figure 28)
The maximum and minimum values are reset on the programming menu. (“4.9.15. *Deleting maximum and minimum values*”)





Figure 28: Analyzer profile screen displaying the maximum values.

✓ **Minimum values**

To see the minimum values of the screen being displayed, press the  key for 2 seconds. These are displayed for 30 seconds. The **min** symbol will be displayed (Figure 29)
The maximum and minimum values are reset on the programming menu. (“4.9.15. *Deleting maximum and minimum values*”)






Figure 29: Analyzer profile screen displaying the minimum values.

✓ Maximum Demand

The device calculates the maximum demand of the following:

- Current
- Three-Phase Active Power.
- Three-Phase Apparent Power.
- Three-Phase Inductive Reactive Power
- Three-Phase Capacitive Reactive Power

This value can be displayed on the display screen of the parameter by pressing the  and  keys at the same time. The **dem** symbol appears on the display (Figure 30)




Figure 30: Analyzer profile screen displaying the maximum demand values.

Press keys  or  to stop displaying the maximum demand values.

The maximum demand values are reset on the programming menu: **"4.9.11. Deleting maximum demand"**

4.5.1.1. Detection of incorrect direction of rotation (Version 4.05 or higher)

The device has a system for detecting the incorrect direction of rotation of the voltages. In other words, if each of the voltages has been correctly connected to the appropriate terminal, L1 to terminal **VL1**, L2 to terminal **VL2** and L3 to terminal **VL3**.

If there is an error in the direction of rotation, the icons **L1**, **L2** and **L3** flash on the display.

The device has a RS-485 communications parameter, which indicates whether an incorrect direction of rotation has been detected ("**4.10.3.7. Detection of incorrect direction of rotation.**")

Note: The detection of the direction of rotation is only enabled for measurement systems: Three-phase network measurement (4-3Ph, 3-3Ph y 3-A-0n) and two-phase network measurement with 3-wire connection (3-2Ph).

4.5.2. e³ PROFILE

This profile is identified with the e³ symbol on the bottom of the screen (Figure 31).




Figure 31: CVM-C10 screen with the e³ profile.

The installation's consumed and generated energy are displayed on the e³ profile of the device.

The installation status is also displayed:

- ▼⊖ Installation is consuming energy.
- ▲⊖ Installation is generating energy.

A long keystroke (3 sec) of key **>** will display the generation values.

The generation values are identified with the negative sign on the screen, which appears in front of each parameter.






A long keystroke (3 sec) of key **<** will display the consumption values.

Use keys **<** and **>** to browse the different screens (short keystroke).

Table 13: Screens of the e³ profile.

| Screen | Parameters (units) |
|--------|---|
| | Active Energy Tariff 1, T1 (M/KWh) Active Energy Tariff 2, T2 (M/KWh) Active Energy Tariff 3, T3 (M/KWh) Total Active Energy (M/KWh) <i>Consumption and generation values</i> <i>Only available for the 4 quadrant option.</i> |
| | Apparent Energy Tariff 1, T1 (M/KVAh) Apparent Energy Tariff 2, T2 (M/KVAh) Apparent Energy Tariff 3, T3 (M/KVAh) Total Apparent Energy (M/KVAh) <i>Consumption and generation values</i> <i>Only available for the 4 quadrant option.</i> |

Table 13 (Continuation): Screens of the e³ profile.

| Screen | Parameters (units) |
|---|---|
|  | Inductive Reactive Energy Tariff 1, T1 (M/Kvar ^L h) Inductive Reactive Energy Tariff 2, T2 (M/Kvar ^L h) Inductive Reactive Energy Tariff 3, T3 (M/Kvar ^L h) Total Inductive Reactive Energy (M/Kvar ^L h) <i>Consumption and generation values</i> <i>Only available for the 4 quadrant option.</i> |
|  | Capacitive Reactive Energy Tariff 1, T1 (M/Kvar _C h) Capacitive Reactive Energy Tariff 2, T2 (M/Kvar _C h) Capacitive Reactive Energy Tariff 3, T3 (M/Kvar _C h) Total Capacitive Reactive Energy (M/Kvar _C h) <i>Consumption and generation values</i> <i>Only available for the 4 quadrant option.</i> |
|  | Cost Tariff 1, T1 (cost) Cost Tariff 2, T2 (cost) Cost Tariff 3, T3 (cost) Total Cost (cost) <i>Consumption and generation values</i> |
|  | CO ₂ Emissions Tariff 1, T1 (kgCO ₂) CO ₂ Emissions Tariff 2, T2 (kgCO ₂) CO ₂ Emissions Tariff 3, T3 (kgCO ₂) Total CO ₂ Emissions (kgCO ₂) <i>Consumption and generation values</i> |
|  | No. of hours Tariff 1, T1(hours) No. of hours Tariff 2, T2(hours) No. of hours Tariff 3, T3(hours) Total No. of hours (hours) |

Symbols **T1**, **T2** and **T3** on the display indicate the three tariffs available on the device. The corresponding symbol flashes to indicate the selected tariff.

4.5.3. USER

This profile is identified with the **user** symbol on the bottom of the screen (Figure 32).




Figure 32: Screen of the CVM-C10 with the user profile.

This profile displays the screens selected in the programming menu ("**4.9.12. Selecting the operation profile**").

Note: If you have not selected the display of any screen, the device will restart and display the **Phase-Neutral Voltage** screen by default.

The voltage and current harmonics are also displayed, up to the 31st order harmonic, for each of the lines, L1, L2 and L3 ("**4.6.- HARMONICS**").

4.6.- HARMONICS

The device can display the voltage and current harmonics, up to the 31st order harmonic, for each one of the lines, L1, L2 and L3.

The display of these can be deactivated using the programming menu ("**4.9.18. Activating the harmonics display screen.**").

Press the **>** key on the last profile screen to show all operation profiles on the harmonics display screens.

Harmonics are displayed as shown on Figure 33.




Figure 33: CVM-C10 Current harmonics screen.

Press key **>** to open the next harmonics screen.

Press key  to display the different types of harmonics:

- Voltage harmonics L1- L2 - L3
- Current harmonics L1- L2 -L3

4.7.- INPUTS

The **CVM-C10** has two digital inputs (terminals 12 and 13 on **Figure 1**, **Figure 2** and **Figure 3**) that can be programmed to operate as a logic or tariff selection input.

If configured as a logic input, the device displays the status of that input.

See *"4.9.27. Operating mode of digital input 1"* and *"4.9.28. Operating mode of digital input 2"*

The selected tariff can be determined in accordance with the status of the inputs, as shown in **Table 14**.

Table 14: Selecting the tariff in accordance with the input status.

| IN1, Input 1 | | IN2, Input 2 | | Tariff |
|--------------|------------------|--------------|------------------|--------|
| Logic input | Tariff selection | Logic input | Tariff selection | |
| x | | x | | T1 |
| x | | | 0 | T1 |
| x | | | 1 | T3 |
| | 0 | x | | T1 |
| | 1 | x | | T2 |
| | 0 | | 0 | T1 |
| | 0 | | 1 | T3 |
| | 1 | | 0 | T2 |
| | 1 | | 1 | T1 |

4.8.- OUTPUTS

The device features:

- ✓ Two alarm relays (terminals 3, 4 and 5, as shown in **Figure 1**, **Figure 2** and **Figure 3**), fully programmable, see *"4.9.23. Programming alarm 1 (Relay 1)"* and *"4.9.24. Programming alarm 2 (Relay 2)"*
- ✓ Two digital outputs, optoisolated NPN transistors (terminals 6, 7 and 8 on **Figure 1** and **Figure 3**), fully programmable, see *"4.9.25. Programming alarm 3 (Digital output T1)"* and *"4.9.26. Programming alarm 4 (Digital output T2)"*.




Note: The digital outputs are not available on models **CVM-C10-ITF-IN**, **CVM-C10-MC-IN** and **CVM-C10-FLEX**

4.9.- PROGRAMMING


From the programming menu you can:

- ✓ Lock the status of the menu.
- ✓ Define the transformation ratios.
- ✓ Select the number of quadrants and type of installation.
- ✓ Select the operation profile of the device.
- ✓ Program the carbon emission ratio, kgCO₂.
- ✓ Program the cost ratio.
- ✓ Program the maximum demand parameters.
- ✓ Delete the energy meters and the maximum and minimum values.
- ✓ Modify the display's backlight.
- ✓ Activate the harmonic display option.
- ✓ Program alarms.
- ✓ Program Modbus communications


The programming parameters are validated as follows:

- ✓ When on reaching the last point on the programming menu ("**4.9.30. Locking the programming**") the key is pressed 
- ✓ At any point in the programming, by pressing the key  or  pressing for 3 seconds.


If the device is RESET before validation or no key is pressed for 30 seconds, the configuration will not be stored in the memory.

To enter the programming menu press the  key for 3 seconds.


The home screen of the menu indicates whether the menu is locked or not:



UnLOC

When you enter the programming menu you can view and modify the programming. Icon  on the display indicates that the unit is not locked.

LOC


When you enter the programming you can view the programming but not modify it. Icon  indicates the locking status.


Press key  to access the first programming step.


The following screen will be displayed if the programming menu is locked, **LOC**:




Enter the password in this screen to modify the programming parameters.

Press key  for 3 seconds to edit the password. The **prog** icon will be displayed on the bottom of the screen.

To enter or modify the value, press the  key repeatedly, increasing the value of the flashing digit.

When the desired value is shown on the screen, move onto the next digit by pressing the key  to modify the other values.

If you press the  key after changing the last digit, it will jump back to the first digit so you can modify the previously programmed values again.


To validate the data, press  for 3 seconds and the **prog** icon will disappear from the display.

If the password is correct, the icon will change its status to not locked .

If you do not enter the password or it is incorrect, you can open the programming menu but it cannot be modified.

The programming menu is unlocked for a short period of time and it will be locked again when you exit the device's menu.

To permanently unlock the device, select the programming parameter **"4.9.30. Locking the programming"**


Press key  to access the next programming step.


Default password: 1234.


4.9.1. PRIMARY VOLTAGE




On this screen the voltage transformer primary is programmed.

Press key  for 3 seconds to edit the transformer primary value. The **prog** icon will be displayed on the bottom of the screen.

To enter or modify the value, press the  key repeatedly, increasing the value of the flashing digit.

When the desired value is shown on the screen, move onto the next digit by pressing the key  to modify the other values.

If you press the  key after changing the last digit, it will jump back to the first digit so you can modify the previously programmed values again.

To validate the data, press  for 3 seconds and the **prog** icon will disappear from the display.

The programmed value will be deleted if the entered value is higher than the maximum programming value.

Maximum programming value: 599999.


Minimum programming value: 1.



Voltage ratio x Primary Current < 600000


Note: The ratio is the relation between the primary and the secondary.


Press key  to access the next programming step.

4.9.2. SECONDARY VOLTAGE



On this screen the voltage transformer secondary is programmed. Press key  for 3 seconds to edit the transformer secondary value. The **prog** icon will be displayed on the bottom of the screen. To enter or modify the value, press the  key repeatedly, increasing the value of the flashing digit.

When the desired value is shown on the screen, move onto the next digit by pressing the key  to modify the other values.

If you press the  key after changing the last digit, it will jump back to the first digit so you can modify the previously programmed values again.

To validate the data, press  for 3 seconds and the **prog** icon will disappear from the display.


The programmed value will be deleted if the entered value is higher than the maximum programming value.



Maximum programming value: 999.


Minimum programming value: 1.


Press key  to access the next programming step.

4.9.3. PRIMARY CURRENT



The current transformer primary is programmed on this screen. Press key  for 3 seconds to edit the transformer primary value. The **prog** icon will be displayed on the bottom of the screen. To enter or modify the value, press the  key repeatedly, increasing the value of the flashing digit.

When the desired value is shown on the screen, move onto the next digit by pressing the key  to modify the remaining values.

If you press the  key after changing the last digit, it will jump back to the first digit so you can modify the previously programmed values again.

To validate the data, press  for 3 seconds and the **prog** icon will disappear from the display.


The programmed value will be deleted if the entered value is higher than the maximum programming value.

Maximum programming value: 10000.

Minimum programming value: 1.

Voltage ratio x Current ratio < 600000


Note: The ratio is the relation between the primary and the secondary.


Press key  to access the next programming step


4.9.4. SECONDARY CURRENT (MODEL CVM-C10-ITF)




On this screen the current transformer secondary is selected.

Press key  for 3 seconds to edit the transformer secondary value. The **prog** icon will be displayed on the bottom of the screen.

Press key  to browse the two possible options for the current transformer secondary (1A or 5A).


To validate the data, press  for 3 seconds and the **prog** icon will disappear from the display.


Press key  to access the next programming step


4.9.5. PRIMARY NEUTRAL CURRENT (MODELS: CVM-C10-ITF-IN AND CVM-C10-MC-IN)




The neutral current transformer primary is programmed on this screen.

Press key  for 3 seconds to edit the transformer primary value. The **prog** icon will be displayed on the bottom of the screen.

To enter or modify the value, press the  key repeatedly, increasing the value of the flashing digit.

When the desired value is shown on the screen, move onto the next digit by pressing the key  to modify the remaining values.


If you press the  key after changing the last digit, it will jump back to the first digit so you can modify the previously programmed values again.

To validate the data, press  for 3 seconds and the **prog** icon will disappear from the display.


The programmed value will be deleted if the entered value is higher than the maximum programming value.

Maximum programming value: 10000.


Minimum programming value: 1.


Press key  to access the next programming step

4.9.6. SECONDARY NEUTRAL CURRENT (MODEL CVM-C10-ITF-IN)




The neutral current transformer secondary is programmed on this screen.

Press key  for 3 seconds to edit the transformer secondary value. The **prog** icon will be displayed on the bottom of the screen.

Press key  to browse the two possible options for the current transformer secondary (1A or 5A).


To validate the data, press  for 3 seconds and the **prog** icon will disappear from the display.


Press key  to access the next programming step

4.9.7. NUMBER OF QUADRANTS




The quadrant number on which the unit takes the measurement is selected on this screen.


Press key  for 3 seconds to edit the number of quadrants. The **prog** icon will be displayed on the bottom of the screen.

Press key  to browse the two options: 2 or 4 quadrants.


To validate the data, press  for 3 seconds and the **prog** icon will disappear from the display.

Press key  to access the next programming step


4.9.8. MEASUREMENT CONVENTION



You can select the measurement convention of the device from this screen.

To edit the measurement convention press key  for 3 seconds. The **prog** icon will be displayed on the bottom of the screen.

The key  is used to browse the different options:

-  **Circutor** measurement convention.
- IEC** IEC measurement convention.
- IEEE** IEEE measurement convention.


To validate the data, press  for 3 seconds and the **prog** icon will disappear from the display.

Press key  to access the next programming step.

4.9.9. TYPE OF INSTALLATION



The type of installation is selected on this screen.

Press key  for 3 seconds to edit the type of installation. The **prog** icon will be displayed on the bottom of the screen.


The  key is used to browse the different options

- 4-3Ph Three-phase network measurement with a 4-wire connection.
- 3-3Ph Three-phase network measurement with a 3-wire connection.
- 3-ARON Three-phase network measurement with a 3-wire connection and transformers with an ARON connection .
- 3-2Ph Two-phase network measurement with a 3-wire connection.
- 2-2Ph Single-phase network measurement, phase to phase, with a 2-wire connection.
- 2-1Ph Single-phase network measurement, phase to neutral, with a 2-wire connection.


To validate the data, press  for 3 seconds and the **prog** icon will disappear from the display.


Press key  to access the next programming step.


4.9.10. MAXIMUM DEMAND INTEGRATION PERIOD




The maximum demand integration period is programmed in minutes on this screen.

Press key  for 3 seconds to edit the integration period value. The **prog** icon will be displayed on the bottom of the screen.

To enter or modify the value, press the  key repeatedly, increasing the value of the flashing digit.

When the desired value is shown on the screen, move onto the next digit by pressing the key  to modify the other values.

If you press the  key after changing the last digit, it will jump back to the first digit so you can modify the previously programmed values again.

To validate the data, press  for 3 seconds and the **prog** icon will disappear from the display.

The programmed value will be deleted if the entered value is higher than the maximum programming value.

Maximum programming value: 60.

Minimum programming value: 0.

Note: Programming the value **0** disables the calculation of the maximum demand.

Press key **>** to access the next programming step.

4.9.11. DELETING MAXIMUM DEMAND



On this screen you select whether or not to delete the maximum demand.

Press key **≡** for 3 seconds to edit the deletion selection. The **prog** icon will be displayed on the bottom of the screen.

Press key **≡** to browse the two deletion options: Yes or No.

To validate the data, press **≡** for 3 seconds and the **prog** icon will disappear from the display.

Press key **>** to access the next programming step

4.9.12. SELECTING THE OPERATION PROFILE



The unit's operation profile is selected on this screen.

Press key **≡** for 3 seconds to edit the operation profile selection. The **prog** icon will be displayed on the bottom of the screen.

Press key **≡** to browse the three profile options:


ANALY Analyzer profile, **analyzer**,
e3 Electrical energy efficiency profile, **e³**,
USER User profile, **user**,

To validate the data, press **≡** for 3 seconds and the **prog** icon will disappear from the display.

Press key **>** to access the next programming step

✓ Selecting the screens that will be displayed (*User profile*)

The following screen is displayed if you have selected the **user** profile:




This screen is used to select whether the unit's display screens are defined by the user or not.

Press key **≡** for 3 seconds to edit the selection. The **prog** icon will be displayed on the bottom of the screen.

Press key **≡** to browse the two profile options:


YES the display screens are those that were stored in previous programming settings of the device. (In the case of new devices, these will be the same as those of the **analyzer** profile)
NO, the display screens are selected.

To validate the data, press  for 3 seconds and the **prog** icon will disappear from the display.


Press key  to access the next programming step

✓ Selecting the screens

The following screen will be displayed if you have selected **NO** :




This screen displays the first screen of the **analyzer** profile, *Phase-phase Voltage* and the **user** profile viewing option can be selected.

Press key  for 3 seconds to edit the selection. The **prog** icon will be displayed on the bottom of the screen.

Press key  to browse the two options:


YES, to display the screen in the user menu.
NO, to stop displaying the screen.

To validate the data, press  for 3 seconds and the **prog** icon will disappear from the display.


Press key  to access the next programming step

This programming step is repeated for each one of the 18 screens of the device.


4.9.13. BACKLIGHT, TURNING ON THE BACKLIT DISPLAY




The time that the Backlight will stay lit (in seconds) is programmed on this screen after the last keystroke on the unit .

Press key  for 3 seconds to edit the backlight value. The **prog** icon will be displayed on the bottom of the screen.

To enter or modify the value, press the  key repeatedly, increasing the value of the flashing digit.

When the desired value is shown on the screen, move onto the next digit by pressing the key  to modify the other values.

If you press the  key after changing the last digit, it will jump back to the first digit so you can modify the previously programmed values again.

To validate the data, press  for 3 seconds and the **prog** icon will disappear from the display.

Maximum programming value: 99 seconds.

Minimum programming value: 0 seconds.


Note: The value **00** indicates that the backlight will stay permanently lit.


Press key  to access the next programming step.

4.9.14. SELECTING THE Cos ϕ - PF BAR ON THE DISPLAY



This screen is used to select the Cos ϕ - PF bar viewing option.

Press key  for 3 seconds to edit the selection. The **prog** icon will be displayed on the bottom of the screen.

Press key  to browse the two viewing options.

Cos Displaying the Cos ϕ .
PF Displaying the Power Factor


To validate the data, press  for 3 seconds and the **prog** icon will disappear from the display.

Press key  to access the next programming step.

4.9.15. DELETING MAXIMUM AND MINIMUM VALUES



On this screen you select whether or not to delete the maximum and minimum values

Press key  for 3 seconds to edit the selection. The **prog** icon will be displayed on the bottom of the screen.

Press key  to browse the two options (Yes and No).


To validate the data, press  for 3 seconds and the **prog** icon will disappear from the display.

Press key  to access the next programming step.

4.9.16. DELETING ENERGY VALUES



On this screen you select whether or not to delete the energy values

Press key  for 3 seconds to edit the selection. The **prog** icon will be displayed on the bottom of the screen.

Press key  to browse the two options (Yes and No).


To validate the data, press  for 3 seconds and the **prog** icon will disappear from the display.


Press key  to access the next programming step.

4.9.17. SELECTING THE RANGE OF ENERGIES



The operation of the range of energy is selected on this screen.



Press key  for 3 seconds to edit the selection. The **prog** icon will be displayed on the bottom of the screen.

Press the  key to browse different options:

AUTO The device displays the kWh and MWh. When the energy value reaches 999999kWh, the device automatically selects the MWh range.


SHORT The device only displays the KWh. When the energy value reaches 999999kWh, the device resets the measurement to 0kWh.

To validate the modification of the range of energies, delete the energy values first.


To do so, press the  validation key for 3 seconds; the energy value deletion screen will be displayed. Select YES to delete the energy values; the device will go back to the energy range selection screen. To complete the validation, press the  key for 3 seconds; the **prog** icon will disappear from the display.

Press key  to access the next programming step.

4.9.18. ACTIVATING THE HARMONICS DISPLAY SCREEN.



This screen is used to select whether harmonics are displayed or not.


Press key  for 3 seconds to edit the selection. The **prog** icon will be displayed on the bottom of the screen.

Press key  to browse the two options (Yes and No).


To validate the data, press  for 3 seconds and the **prog** icon will disappear from the display.

Press key  to access the next programming step.

4.9.19. kgCO₂ CARBON EMISSION RATIO OF GENERATED ENERGY





The carbon emissions ratio is the amount of emissions released into the atmosphere to produce a unit of electricity (1 kWh). The ratio for the European mix is approximately 0.65 kgCO₂ per kWh.


Press key  for 3 seconds to edit the emission ratio selection. The **prog** icon will be displayed on the bottom of the screen.

The emission ratio of the 3 tariffs of the device, T1, T2 and T3, is programmed on this screen.

To enter or modify the value, press the  key repeatedly, increasing the value of the flashing digit.

When the desired value is shown on the screen, move onto the next digit by pressing the key  to modify the other values.

If you press the  key after changing the last digit, it will jump back to the first digit so you can modify the previously programmed values again.

Press key  to browse the different tariffs.

To validate the data, press  for 3 seconds and the **prog** icon will disappear from the display.

The programmed value will be deleted if the entered value is higher than the maximum programming value.

Maximum programming value: 1.9999.


Minimum programming value: 0.

Press key  to access the next programming step.

4.9.20. kgCO₂ CARBON EMISSION RATIO OF CONSUMED ENERGY





The carbon emissions ratio is the amount of emissions released into the atmosphere to produce a unit of electricity (1 kWh). The ratio for the European mix is approximately 0.65 kgCO₂ per kWh.

Press key  for 3 seconds to edit the emission ratio selection. The **prog** icon will be displayed on the bottom of the screen.

The emission ratio of the 3 tariffs of the device, T1, T2 and T3, is programmed on this screen.

To enter or modify the value, press the  key repeatedly, increasing the value of the flashing digit.

When the desired value is shown on the screen, move onto the next digit by pressing the key  to modify the other values.

If you press the  key after changing the last digit, it will jump back to the first digit so you can modify the previously programmed values again.

Press key  to browse the different tariffs.

To validate the data, press  for 3 seconds and the **prog** icon will disappear from the display.


The programmed value will be deleted if the entered value is higher than the maximum programming value.

Maximum programming value: 1.9999.


Minimum programming value: 0.


Press key  to access the next programming step.


4.9.21. COST RATIO OF GENERATED ENERGY




The cost per kWh of electricity of the three tariffs of the unit is calculated on this screen.

Press key  for 3 seconds to edit the cost ratio selection. The **prog** icon will be displayed on the bottom of the screen.

To enter or modify the value, press the  key repeatedly, increasing the value of the flashing digit.

When the desired value is shown on the screen, move onto the next digit by pressing the key  to modify the other values.

If you press the  key after changing the last digit, it will jump back to the first digit so you can modify the previously programmed values again.

Press key  to browse the different tariffs.

To validate the data, press  for 3 seconds and the **prog** icon will disappear from the display.


The programmed value will be deleted if the entered value is higher than the maximum programming value.

Maximum programming value: 1.9999.


Minimum programming value: 0.


Press key  to access the next programming step.


4.9.22. COST RATIO OF CONSUMED ENERGY




The cost per kWh of electricity of the three tariffs of the unit is calculated on this screen.

Press key  for 3 seconds to edit the cost ratio selection. The **prog** icon will be displayed on the bottom of the screen.

To enter or modify the value, press the  key repeatedly, increasing the value of the flashing digit.

When the desired value is shown on the screen, move onto the next digit by pressing the key  to modify the other values.

If you press the  key after changing the last digit, it will jump back to the first digit so you can modify the previously programmed values again.

Press key  to browse the different tariffs.

To validate the data, press  for 3 seconds and the **prog** icon will disappear from the display.

The programmed value will be deleted if the entered value is higher than the maximum programming value.


Maximum programming value: 1.9999.

Minimum programming value: 0.


Press key  to access the next programming step.

4.9.23. PROGRAMMING ALARM 1 (RELAY 1)


Note: Configuration parameters not available for the **CVM-C10-FLEX** model.




The variable code is selected on this screen, depending on **Table 15**, which will control alarm relay 1.

Press key  for 3 seconds to edit the code selection. The **prog** icon will be displayed on the bottom of the screen.

To enter or modify the value, press the  key repeatedly, increasing the value of the flashing digit.

When the desired value is shown on the screen, move onto the next digit by pressing the key  to modify the other values.

When you enter the code of a variable on the display, the symbols for that variable will be activated. Set the value to 00 if you do not wish to program a variable.

If you press the  key after changing the last digit, it will jump back to the first digit so you can modify the previously programmed values again.



To validate the data, press  for 3 seconds and the **prog** icon will disappear from the display. Press key  to access the next programming step.

Table 15: Parameter codes used to program the outputs.


| Parameter | Phase | Code | Phase | Code | Phase | Code | Phase | Code |
|--|-------|------|-------|------|-------|------|-------|------|
| Phase-Neutral Voltage | L1 | 01 | L2 | 09 | L3 | 17 | - | - |
| Current | L1 | 02 | L2 | 10 | L3 | 18 | - | - |
| Active power | L1 | 03 | L2 | 11 | L3 | 19 | III | 25 |
| Inductive Reactive Power | L1 | 04 | L2 | 12 | L3 | 20 | III | 26 |
| Capacitive Reactive Power | L1 | 05 | L2 | 13 | L3 | 21 | III | 27 |
| Apparent power | L1 | 06 | L2 | 14 | L3 | 22 | III | 28 |
| Power factor | L1 | 07 | L2 | 15 | L3 | 23 | III | 29 |
| Cosine ϕ | L1 | 08 | L2 | 16 | L3 | 24 | III | 30 |
| % THD V | L1 | 36 | L2 | 37 | L3 | 38 | - | - |
| % THD A | L1 | 39 | L2 | 40 | L3 | 41 | - | - |
| Phase-Phase Voltage | L1/2 | 32 | L2/3 | 33 | L3/1 | 34 | - | - |
| Frequency | - | 31 | - | - | - | - | - | - |
| Neutral current | - | 35 | - | - | - | - | - | - |
| Maximum current demand | L1 | 45 | L2 | 46 | L3 | 47 | III | 44 |
| Active Power Maximum Demand | - | - | - | - | - | - | III | 42 |
| Apparent Power Maximum Demand | - | - | - | - | - | - | III | 43 |
| Inductive Reactive Power Maximum Demand | - | - | - | - | - | - | III | 132 |
| Capacitive Reactive Power Maximum Demand | - | - | - | - | - | - | III | 133 |

In addition, there are some parameters (Table 16) that refer to the three phases at the same time (OR function). If you have selected one of these variables, the alarm will be activated when any of the three phases meets the programmed conditions.


Table 16: Multiple parameter codes for alarm programming.


| Types of parameters | Code |
|---------------------------|------|
| Phase-Neutral Voltage | 200 |
| Current | 201 |
| Active power | 202 |
| Inductive Reactive Power | 203 |
| Capacitive Reactive Power | 204 |
| Power factor | 205 |
| Phase-Phase Voltage | 206 |
| % THD V | 207 |
| % THD A | 208 |
| Apparent Power | 209 |


✓ Programming the maximum value




The **maximum value**: the alarm is activated when this value is exceeded.



Press key  for 3 seconds to edit the maximum value selection. The **prog** icon will be displayed on the bottom of the screen.

To enter or modify the value, press the  key repeatedly, increasing the value of the flashing digit.

When the desired value is shown on the screen, move onto the next digit by pressing the key  to modify the other values.

In the case of some parameters (Table 17), you can modify the position of the decimal point. To do so, press key  after modifying the last digit and the decimal point will start flashing.

Press key  repeatedly to modify the position of the decimal point.

When the decimal point is in the desired position, press the key  to end the programming, pressing now the key  we can set a positive or negative value.

Note: Pay special attention when programming the Generation Power (displayed with negative values).

Example: If you wish to enter a generation power alarm with limits between 2 kW and 1 kW, program the following as the **maximum value** : - 1 kW and the following as the **minimum value** : - 2 kW.




To validate the data, press  for 3 seconds and the **prog** icon will disappear from the display. Press key  to access the next programming step


Table 17: Decimal point and units of the alarm parameters.


| Types of parameters | Units | Decimal point |
|------------------------|---|---------------|
| Voltage | 2000 V 200.0 V 20.00 kV 2.000 kV | Programmable |
| Current | A | Programmable |
| Frequency | Hz | Fixed |
| Power | kW | Programmable |
| Power factor | PF | Fixed |
| Cosine φ | φ | Fixed |
| Maximum current demand | A | Programmable |
| Maximum power demand | kW | Programmable |
| THD | % | Fixed |


✓ Programming the minimum value




The **minimum value**: the alarm is activated below this value.



Press key  for 3 seconds to edit the minimum value selection. The **prog** icon will be displayed on the bottom of the screen.

To enter or modify the value, press the  key repeatedly, increasing the value of the flashing digit.

When the desired value is shown on the screen, move onto the next digit by pressing the key  to modify the other values.

In the case of some parameters (**Table 17**) you can modify the position of the decimal point. To do so, Press key  after modifying the last digit and the decimal point will start flashing.

Press key  repeatedly to modify the position of the decimal point.

When the decimal point is in the desired position, press the key  to end the programming, pressing now the key  we can set a positive or negative value.

Note: Pay special attention when programming the Generation Power (displayed with negative values).

Example: If you wish to enter a generation power alarm with limits between 2 kW and 1 kW, program the following as the **maximum value** : - 1 kW and the following as the **minimum value** : - 2 kW.


To validate the data, press  for 3 seconds and the **prog** icon will disappear from the display.


Press key  to access the next programming step.


✓ Programming the connection time delay




The alarm connection delay is programmed on this screen in seconds.


Press key  for 3 seconds to edit the delay selection. The **prog** icon will be displayed on the bottom of the screen.

To enter or modify the value, press the  key repeatedly, increasing the value of the flashing digit.


When the desired value is shown on the screen, move onto the next digit by pressing the key  to modify the other values.

If you press the  key after changing the last digit, it will jump back to the first digit so you can modify the previously programmed values again.


To validate the data, press  for 3 seconds and the **prog** icon will disappear from the display.


Press key  to access the next programming step.


✓ Programming the hysteresis value






The hysteresis value, i.e., difference between the alarm connection and disconnection value, in %, is programmed on this screen.

Press key  for 3 seconds to edit the hysteresis value selection. The **prog** icon will be displayed on the bottom of the screen.

To enter or modify the value, press the  key repeatedly, increasing the value of the flashing digit.

When the desired value is shown on the screen, move onto the next digit by pressing the key  to modify the other values.


If you press the  key after changing the last digit, it will jump back to the first digit so you can modify the previously programmed values again.

To validate the data, press  for 3 seconds and the **prog** icon will disappear from the display. Press key  to access the next programming step.

✓ Programming the latch



The interlocking is selected on this screen, i.e., if the alarm is interlocked after it has been tripped, even when the condition that triggered it has disappeared.

Press key  for 3 seconds to edit the selection. The **prog** icon will be displayed on the bottom of the screen.

Press key  to browse the two options (Yes and No).

To validate the data, press  for 3 seconds and the **prog** icon will disappear from the display.


Press key  to access the next programming step.


Note: If the device is reset, the status of alarms is deleted and all alarms will return to the programmed standby status, provided that the condition that triggered them has been resolved.


✓ Programming the time delay 2




The alarm disconnection delay is programmed on this screen in seconds.

Press key  for 3 seconds to edit the maximum value selection. The **prog** icon will be displayed on the bottom of the screen.

To enter or modify the value, press the  key repeatedly, increasing the value of the flashing digit.

When the desired value is shown on the screen, move onto the next digit by pressing the key  to modify the other values.

If you press the  key after changing the last digit, it will jump back to the first digit so you can modify the previously programmed values again.


To validate the data, press  for 3 seconds and the **prog** icon will disappear from the display.

Press key  to access the next programming step.

✓ Programming the contact status



The status of relay contacts is selected on this screen.


Press key  for 3 seconds to edit the selection. The **prog** icon will be displayed on the bottom of the screen.

Press key  to browse the two options:

NO Normally open contact.


NC Normally closed contact.

To validate the data, press  for 3 seconds and the **prog** icon will disappear from the display.

Press key  to access the next programming step

4.9.24. PROGRAMMING ALARM 2 (RELAY 2)

Note: Configuration parameters not available for the **CVM-C10-FLEX** model.




The values for alarm relay 2 are programmed on this screen.

They are programmed as in the case of alarm relay 1, see "4.9.23. Programming alarm 1 (Relay 1)"


4.9.25. PROGRAMMING ALARM 3 (DIGITAL OUTPUT T1)

Note: Configuration parameters not available for the **CVM-C10-FLEX**, **CVM-C10-ITF-IN** and **CVM-C10-MC-IN** models.




All values for digital output T1 are programmed on this screen.

The variable code is selected on this screen, depending on **Table 15** and **Table 18**, which will control digital output T1.


Press key  for 3 seconds to edit the code selection. The **prog** icon will be displayed on the bottom of the screen.

Press key  for 3 seconds to edit the code selection. The **prog** icon will be displayed on the bottom of the screen.

To enter or modify the value, press the  key repeatedly, increasing the value of the flashing digit.

When the desired value is shown on the screen, move onto the next digit by pressing the key  to modify the other values.

When you enter the code of a variable on the display, the symbols for that variable will be activated. Set the value to **00** if you do not wish to program a variable.

If you press the  key after changing the last digit, it will jump back to the first digit so you can modify the previously programmed values again.



To validate the data, press  for 3 seconds and the **prog** icon will disappear from the display. Press key  to access the next programming step

Table 18: Parameter codes used to program digital outputs.


| Parameter | Tariff | Code | Tariff | Code | Tariff | Code | Tariff | Code |
|--------------------------------------|--------|------|--------|------|--------|------|--------|------|
| Consumed Active Energy | T1 | 49 | T2 | 70 | T3 | 91 | total | 112 |
| Generated Active Energy | T1 | 59 | T2 | 80 | T3 | 101 | total | 122 |
| Consumed Inductive Reactive Energy | T1 | 51 | T2 | 72 | T3 | 93 | total | 114 |
| Generated Inductive Reactive Energy | T1 | 61 | T2 | 82 | T3 | 103 | total | 124 |
| Consumed Capacitive Reactive Energy | T1 | 53 | T2 | 74 | T3 | 95 | total | 116 |
| Generated Capacitive Reactive Energy | T1 | 63 | T2 | 84 | T3 | 105 | total | 126 |
| Consumed Apparent Energy | T1 | 55 | T2 | 76 | T3 | 97 | total | 118 |
| Generated Apparent Energy | T1 | 65 | T2 | 86 | T3 | 107 | total | 128 |
| Consumed CO ₂ Emissions | T1 | 56 | T2 | 77 | T3 | 98 | total | 119 |
| Generated CO ₂ Emissions | T1 | 66 | T2 | 87 | T3 | 108 | total | 129 |
| Consumption Cost | T1 | 57 | T2 | 78 | T3 | 99 | total | 120 |
| Generation Cost | T1 | 67 | T2 | 88 | T3 | 109 | total | 130 |
| No. of hours | T1 | 68 | T2 | | T3 | 110 | total | 131 |


If you have selected a parameter from **Table 12** the subsequent programming steps are the same as for alarm relay 1, see ("**4.9.23. Programming alarm 1 (Relay 1)**")


If you have selected a parameter from **Table 18**, the subsequent programming steps are:


✓ Programming kilowatts per pulse





Press key  for 3 seconds to edit the kilowatts per pulse selection. The **prog** icon will be displayed on the bottom of the screen.

To enter or modify the value, press the  key repeatedly, increasing the value of the flashing digit.

When the desired value is shown on the screen, move onto the next digit by pressing the key  to modify the other values.

If you press the  key after changing the last digit, it will jump back to the first digit so you can modify the previously programmed values again.

To validate the data, press  for 3 seconds and the **prog** icon will disappear from the display.

Press key  to access the next programming step.

The programmed value will be deleted if the entered value is higher than the maximum programming value.

Maximum programming value: 999.999 KWh

Minimum programming value: 000.001 KWh


Example: To program 500 Wh per pulse: 000.500


To program 1.5 kWh per pulse: 001.500


✓ Programming the pulse width




The width of the pulse is selected on this screen in ms.

Press key  for 3 seconds to edit the pulse width selection. The **prog** icon will be displayed on the bottom of the screen.

To enter or modify the value, press the  key repeatedly, increasing the value of the flashing digit.

When the desired value is shown on the screen, move onto the next digit by pressing the key  to modify the other values.

If you press the  key after changing the last digit, it will jump back to the first digit so you can modify the previously programmed values again.

To validate the data, press  for 3 seconds and the **prog** icon will disappear from the display.

Press key  to access the next programming step.

The programmed value will be deleted if the entered value is higher than the maximum programming value.

Maximum programming value: 500 ms.

Minimum programming value: 30 ms.

4.9.26. PROGRAMMING ALARM 4 (DIGITAL OUTPUT T2)

Note: Configuration parameters not available for the *CVM-C10-FLEX*, *CVM-C10-ITF-IN* and *CVM-C10-MC-IN* models.




All values for digital output T2 are programmed on this screen.

They are programmed as in the case of digital output T1, see "4.9.25. Programming alarm 3 (Digital output T1)"

4.9.27. OPERATING MODE OF DIGITAL INPUT 1



The function of digital input 1 is selected on this screen.

Press key  for 3 seconds to edit the function selection. The **prog** icon will be displayed on the bottom of the screen.

Press key  to browse the two options:

LoG, c Logic input
tAr, FF Tariff selection.


To validate the data, press  for 3 seconds and the **prog** icon will disappear from the display.

Press key  to access the next programming step.

4.9.28. OPERATING MODE OF DIGITAL INPUT 2



The function of digital input 2 is selected on this screen.

Press key  for 3 seconds to edit the function selection. The **prog** icon will be displayed on the bottom of the screen.


Press key  to browse the two options:

LoG, c Logic input
tAr, FF Tariff selection.


To validate the data, press  for 3 seconds and the **prog** icon will disappear from the display.


Press key  to access the next programming step.

4.9.29. RS-485 COMMUNICATIONS: PROTOCOL





The RS-485 communications protocol is selected on this screen.

Press the  key for 3 seconds to edit the function selection. The **prog** icon will be displayed on the bottom of the screen.

Press key  to browse the two options:

Modbus
BACnet

To validate the data, press  for 3 seconds and the **prog** icon will disappear from the display. Press key  to access the next programming step.


Note: The device will restart after exiting the setup menu if the RS-485 communications parameters have been modified.


4.9.29.1 Modbus protocol

✓ Transmission speed



The transmission speed of modbus communications is programmed on this screen.


Press key  for 3 seconds to edit the transmission speed selection. The **prog** icon will be displayed on the bottom of the screen.

Press key  to browse the two options: **9600** or **19200**.


To validate the data, press  for 3 seconds and the **prog** icon will disappear from the display.


Press key  to access the next programming step.


✓ Peripheral number



The peripheral number is programmed on this screen.

Press key  for 3 seconds to edit the peripheral number selection. The **prog** icon will be displayed on the bottom of the screen.

To enter or modify the value, press the  key repeatedly, increasing the value of the flashing digit.

When the desired value is shown on the screen, move onto the next digit by pressing the key  to modify the other values.

If you press the  key after changing the last digit, it will jump back to the first digit so you can modify the previously programmed values again.

The peripheral number ranges from 0 to 255.


To validate the data, press  for 3 seconds and the **prog** icon will disappear from the display.


Press key  to access the next programming step.

✓ Parity



The type of parity of Modbus communications is selected on this screen.

Press key  for 3 seconds to edit the parity type selection. The **prog** icon will be displayed on the bottom of the screen.

Press key  to browse the options:

no no parity
EVEN even parity.
odd odd parity.


To validate the data, press  for 3 seconds and the **prog** icon will disappear from the display.

Press key  to access the next programming step.

✓ Number of data bits



The number of data bits of Modbus communications are programmed on this screen.

Press key  for 3 seconds to edit the bit number selection. The **prog** icon will be displayed on the bottom of the screen.

Press key  to browse the two options: **7** or **8** bits.


To validate the data, press  for 3 seconds and the **prog** icon will disappear from the display.


Press key  to access the next programming step.

✓ Number of Stop bits



The number of Stop bits of Modbus communications are programmed on this screen.

Press key  for 3 seconds to edit the Stop bits number selection. The **prog** icon will be displayed on the bottom of the screen.

Press key  to browse the options: **1** or **2** bits.

To validate the data, press  for 3 seconds and the **prog** icon will disappear from the display.

Press key  to access the next programming step.



4.9.29.2 BACnet protocol

Note: Protocol available in devices with version 3.00 or higher.


✓ Transmission speed



The transmission speed of BACnet communications is programmed on this screen.

Press key  for 3 seconds to edit the transmission speed selection. The **prog** icon will be displayed on the bottom of the screen. Press key  to browse the two options: **9600** or **19200**.



To validate the data, press  for 3 seconds and the **prog** icon will disappear from the display.

Press key  to access the next programming step.


✓ Device ID



The device ID is programmed on this screen.



Press the  key for 3 seconds to edit the value. The **prog** icon will be displayed on the bottom of the screen. To enter or modify the value, press the  key repeatedly, increasing the value of the flashing digit.

When the desired value is shown on the screen, press the  key to go to the next digit and modify the other values.


If you press the  key after changing the last digit, it will jump back to the first digit so you can modify the previously programmed values again.

Maximum programming value: 999999.



Minimum programming value: 0.


To validate the data, press  for 3 seconds and the **prog** icon will disappear from the display. Press key  to access the next programming step.

✓ MAC



The MAC address is programmed on this screen.



Press the  key for 3 seconds to edit the value. The **prog** icon will be displayed on the bottom of the screen. To enter or modify the value, press the  key repeatedly, increasing the value of the flashing digit.

When the desired value is shown on the screen, press the  key to go to the next digit and modify the other values.

If you press the  key after changing the last digit, it will jump back to the first digit so you can modify the previously programmed values again.

Maximum programming value: 255.


Minimum programming value: 0.

To validate the data, press  for 3 seconds and the **prog** icon will disappear from the display. Press key  to access the next programming step.

4.9.30. LOCKING THE PROGRAMMING




This screen is for protecting the data configured in the programming menu.


Press key  for 3 seconds to edit the locking/unlocking selection. The **prog** icon will be displayed on the bottom of the screen.

Press key  to browse the two options:

unLo

When you enter the programming menu you can view and modify the programming. Icon  on the display indicates the permanently locked status.

Loc


When you enter the programming you can view the programming but not modify it. Icon  indicates the locking status. Enter the password to modify the programming values.


To validate the data, press  for 3 seconds and the **prog** icon will disappear from the display.


Press the  key to enter the password for locking and unlocking the programming:




On this screen you enter the password for locking and unlocking the programming.

Press key  for 3 seconds to edit the password selection. The **prog** icon will be displayed on the bottom of the screen.


To enter or modify the value, press the  key repeatedly, increasing the value of the flashing digit.

When the desired value is shown on the screen, move onto the next digit by pressing the key  to modify the other values.

If you press the  key after changing the last digit, it will jump back to the first digit so you can modify the previously programmed values again.

To validate the data, press  for 3 seconds and the **prog** icon will disappear from the display.

Default password: 1234.

This value may only be modified through communications. See "[4.10.3.8.17. Password configuration.](#)"
Press the  key to exit the setup menu.

Note: *The device will restart after exiting the setup menu if the RS-485 communications parameters have been modified.*

4.10.- COMMUNICATIONS

The **CVM-C10** devices have one RS-485 communications port.

The device has as standard two communications protocols: **MODBUS RTU** ® and **BACnet**.

The protocol and configuration parameters are selected in the setup menu. ("4.9.29. RS-485 communications: Protocol")

Note: BACnet protocol available in devices with version 3.00 or higher.

4.10.1. CONNECTIONS

The RS-485 cable must be wired with twisted pair cable with mesh shield (minimum 3 wires), with a maximum distance between the **CVM-C10** and the master device of 1200 metres.

A maximum of 32 **CVM-C10** devices can be connected to this bus.

Use an intelligent RS-232 to RS-485 network protocol converter to establish the communications with the master device.




Figure 34: RS-485 Connection diagram.

4.10.2. PROTOCOL

In the Modbus protocol, the **CVM-C10** device uses the RTU (Remote Terminal Unit) mode.

The Modbus functions implemented in the device are as follows:

Function 0x03 and 0x04: Reading integer logs.

Function 0x05: Writing a relay.

Function 0x10: Writing multiple logs.

4.10.2.1 Reading example : Function 0x04.

Question: Instantaneous value of the phase voltage of L1

| Address | Function | Initial Register | No. of Registers | CRC |
|---------|----------|------------------|------------------|------|
| 0A | 04 | 0000 | 0002 | 70B0 |

Address: 0A, Peripheral number: 10 in decimals.

Function: 04, Read function.

Initial Register: 0000, on which the reading will start.

No. of Registers: 0002, number of registers read.

CRC: 70B0, CRC Character.

Response:

| Address | Function | No. of Bytes | Register No. 1 | Register No. 2 | CRC |
|---------|----------|--------------|----------------|----------------|------|
| 0A | 04 | 04 | 0000 | 084D | 8621 |

Address: 0A, Responding peripheral number: 10 in decimals.

Function: 04, Read function.

No. of bytes: 04, No. of bytes received.

Registers: 0000084D, value of the phase voltage of L1: VL1 x 10 : 212.5V

CRC: 8621, CRC Character.

Note: Every Modbus frame has a maximum limit of 20 variables (40 logs).

4.10.2.2. Writing example: 0x05 function.

Question: Deleting maximum and minimum values.

| Address | Function | Initial Register | Value | CRC |
|---------|----------|------------------|-------|------|
| 0A | 05 | 0834 | FF00 | CEEF |

Address: 0A, Peripheral number: 10 in decimal.

Function: 05, Read function.

Initial Register: 0834, Register of the parameter for deleting maximum and minimum values.

Value: FF00, we indicate that we want to delete the maximum and minimum values.

CRC: CEEF, CRC character.

Response:

| Address | Function | Initial Register | Value | CRC |
|---------|----------|------------------|-------|------|
| 0A | 05 | 0834 | FF00 | CEEF |

4.10.3. MODBUS COMMANDS

4.10.3.1. Measurement variables.

All the addresses of Modbus memory are in Hexadecimal.

For these variables is implemented the **Function 0x03** and **0x04**.

Table 19: Modbus memory map (Table 1)

| Parameter | Symbol | Instantaneous | Maximum | Minimum | Units |
|------------------------------|-------------------|---------------|---------|---------|---------|
| L1 Phase voltage | V 1 | 00-01 | 106-107 | 164-165 | V x 10 |
| L1 Current | A 1 | 02-03 | 108-109 | 166-167 | mA |
| L1 Active Power | kW 1 | 04-05 | 10A-10B | 168-169 | W |
| L1 Inductive Power | kvarL 1 | 06-07 | 10C-10D | 16A-16B | var |
| L1 Capacitive Power | kvarC 1 | 08-09 | 10E-10F | 16C-16D | var |
| L1 Apparent Power | kVA 1 | 0A-0B | 110-111 | 16E-16F | VA |
| L1 Power Factor | PF 1 | 0C-0D | 112-113 | 170-171 | x 100 |
| Cos φ L1 | Cos φ 1 | 0E-0F | 114-115 | 172-173 | x 100 |
| L2 Phase voltage | V 2 | 10-11 | 116-117 | 174-175 | V x 10 |
| L2 Current | A 2 | 12-13 | 118-119 | 176-177 | mA |
| L2 Active Power | kW 2 | 14-15 | 11A-11B | 178-179 | W |
| L2 Inductive Power | kvarL 2 | 16-17 | 11C-11D | 17A-17B | var |
| L2 Capacitive Power | kvarC 2 | 18-19 | 11E-11F | 17C-17D | var |
| L2 Apparent Power | kVA 2 | 1A-1B | 120-121 | 17E-17F | VA |
| L2 Power Factor | PF 2 | 1C-1D | 122-123 | 180-181 | x 100 |
| Cos φ L2 | Cos φ 2 | 1E-1F | 124-125 | 182-183 | x 100 |
| L3 Phase voltage | V 3 | 20-21 | 126-127 | 184-185 | V x 10 |
| L3 Current | A 3 | 22-23 | 128-129 | 186-187 | mA |
| L3 Active Power | kW 3 | 24-25 | 12A-12B | 188-189 | W |
| L3 Inductive Power | kvarL 3 | 26-27 | 12C-12D | 18A-18B | var |
| L3 Capacitive Power | kvarC 3 | 28-29 | 12E-12F | 18C-18D | var |
| L3 Apparent Power | kVA 3 | 2A-2B | 130-131 | 18E-18F | VA |
| L3 Power Factor | PF 3 | 2C-2D | 132-133 | 190-191 | x 100 |
| Cos φ L3 | Cos φ 3 | 2E-2F | 134-135 | 192-193 | x 100 |
| Active Three-phase Power | kW III | 30-31 | 136-137 | 194-195 | W |
| Inductive Three-phase power | kvarL III | 32-33 | 138-139 | 196-197 | var |
| Capacitive Three-phase Power | kvarC III | 34-35 | 13A-13B | 198-199 | var |
| Apparent three-phase power | kVA III | 36-37 | 13C-13D | 19A-19B | VA |
| Three-phase Power Factor | PF III | 38-39 | 13E-13F | 19C-19D | x100 |
| Three-phase Cos φ | Cos φ III | 3A-3B | 140-141 | 19E-19F | x100 |
| L1 Frequency | Hz | 3C-3D | 142-143 | 1A0-1A1 | Hz x100 |
| L1-L2 Voltage | V12 | 3E-3F | 144-145 | 1A2-1A3 | V x 10 |
| L2-L3 Voltage | V23 | 40-41 | 146-147 | 1A4-1A5 | V x 10 |

Table 19 (Continuation): Modbus memory map (Table 1)

| Parameter | Symbol | Instantaneous | Maximum | Minimum | Units |
|--------------------------|---------|---------------|---------|---------|--------|
| L3-L1 Voltage | V31 | 42-43 | 148-149 | 1A6-1A7 | V x 10 |
| Neutral Current N | A N | 44-45 | 14A-14B | 1A8-1A9 | mA |
| L1 voltage % THD | %THDV1 | 46-47 | 14C-14D | 1AA-1AB | % x 10 |
| L2 voltage % THD | %THDV2 | 48-49 | 14E-14F | 1AC-1AD | % x 10 |
| L3 voltage % THD | %THDV3 | 4A-4B | 150-151 | 1AE-1AF | % x 10 |
| L1 current % THD | %THDI1 | 4C-4D | 152-153 | 1B0-1B1 | % x 10 |
| L2 current % THD | %THDI2 | 4E-4F | 154-155 | 1B2-1B3 | % x 10 |
| L3 current % THD | %THDI3 | 50-51 | 156-157 | 1B4-1B5 | % x 10 |
| Maximum demand kW III | Md (Pd) | 52-53 | 158-159 | - | W |
| Maximum demand kVA III | Md (Pd) | 54-55 | 15A-15B | - | VA |
| Maximum demand I AVG | Md (Pd) | 56-57 | 15C-15D | - | mA |
| Maximum demand I L1 | Md (Pd) | 58-59 | 15E-15F | - | mA |
| Maximum demand I L2 | Md (Pd) | 5A-5B | 160-161 | - | mA |
| Maximum demand I L3 | Md (Pd) | 5C-5D | 162-163 | - | mA |
| Maximum demand kvarL III | kvarL | 200-201 | 204-205 | - | kvarL |
| Maximum demand kvarC III | kvarC | 202-203 | 206-207 | - | kvarC |

4.10.3.2. Energy variables

All the addresses of Modbus memory are in Hexadecimal.

For these variables is implemented the **Function 0x03** and **0x04**.

Table 20: Modbus memory map (Table 2)

| Parameter | Symbol | Tariff 1 | Tariff 2 | Tariff 3 | Total | Units |
|---|-------------------|----------|----------|----------|-------|-------|
| Consumed active energy (kW) | kWh III | 5E-5F | 88-89 | B2-B3 | DC-DD | kWh |
| Consumed active energy (W) | kWh III | 60-61 | 8A-8B | B4-B5 | DE-DF | Wh |
| Consumed inductive reactive energy (kvarhL) | kvarhL III | 62-63 | 8C-8D | B6-B7 | E0-E1 | kvarh |
| Consumed inductive reactive energy (varhL) | kvarhL III | 64-65 | 8E-8F | B8-B9 | E2-E3 | varh |
| Consumed capacitive reactive energy (kvarhC) | kvarhC III | 66-67 | 90-91 | BA-BB | E4-E5 | kvarh |
| Consumed capacitive reactive energy (varhC) | kvarhC III | 68-69 | 92-93 | BC-BD | E6-E7 | varh |
| Consumed apparent energy (kVAh) | kVAh III | 6A-6B | 94-95 | BE-BF | E8-E9 | kVAh |
| Consumed apparent energy (VAh) | kVAh III | 6C-6D | 96-97 | C0-C1 | EA-EB | VAh |
| Consumed CO ₂ emissions | KgCO ₂ | 6E-6F | 98-99 | C2-C3 | EC-ED | x10 |
| Consumption cost | \$ | 70-71 | 9A-9B | C4-C5 | EE-EF | x10 |
| Generated active energy (kW) | kWh III | 72-73 | 9C-9D | C6-C7 | F0-F1 | kWh |
| Generated active energy (W) | kWh III | 74-75 | 9E-9F | C8-C9 | F2-F3 | Wh |
| Generated inductive reactive energy (kvarhL) | kvarhL III | 76-77 | A0-A1 | CA-CB | F4-F5 | kvarh |
| Generated inductive reactive energy (varhL) | kvarhL III | 78-79 | A2-A3 | CC-CD | F6-F7 | varh |
| Generated capacitive reactive energy (kvarhC) | kvarhC III | 7A-7B | A4-A5 | CE-CF | F8-F9 | kvarh |

Table 20 (Continuation): Modbus memory map (Table 2)

| Parameter | Symbol | Tariff 1 | Tariff 2 | Tariff 3 | Total | Units |
|--|-------------------|----------|----------|----------|---------|-------|
| Generated capacitive reactive energy (varhC) | kvarhC III | 7C-7D | A6-A7 | D0-D1 | FA-FB | varh |
| Generated apparent energy (kVAh) | kVAh III | 7E-7F | A8-A9 | D2-D3 | FC-FD | kVAh |
| Generated apparent energy (VAh) | kVAh III | 80-81 | AA-AB | D4-D5 | FE-EF | VAh |
| Generated CO ₂ emissions | KgCO ₂ | 82-83 | AC-AD | D6-D7 | 100-101 | x10 |
| Generation Cost | \$ | 84-85 | AE-AF | D8-D9 | 102-103 | x10 |
| Hours per tariff | Hours | 86-87 | B0-B1 | DA-DB | 104-105 | sec |

4.10.3.3. Voltage and current harmonics.

All the addresses of Modbus memory are in Hexadecimal.

For these variables is implemented the **Function 0x03** and **0x04**.

Table 21: Modbus memory map (Table 3).

| Parameter | L1 Voltage | L2 Voltage | L3 Voltage | Units |
|---------------------|------------|------------|------------|--------|
| Fundamental Harm. | A28-A29 | A48-A49 | A68-A69 | V x 10 |
| 2nd Order harmonic | A2A | A4A | A6A | % x 10 |
| 3rd Order harmonic | A2B | A4B | A6B | % x 10 |
| 4th Order harmonic | A2C | A4C | A6C | % x 10 |
| 5th Order harmonic | A2D | A4D | A6D | % x 10 |
| 6th Order harmonic | A2E | A4E | A6E | % x 10 |
| 7th Order harmonic | A2F | A4F | A6F | % x 10 |
| 8th Order harmonic | A30 | A50 | A70 | % x 10 |
| 9th Order harmonic | A31 | A51 | A71 | % x 10 |
| 10th Order harmonic | A32 | A52 | A72 | % x 10 |
| 11th Order harmonic | A33 | A53 | A73 | % x 10 |
| 12th Order harmonic | A34 | A54 | A74 | % x 10 |
| 13th Order harmonic | A35 | A55 | A75 | % x 10 |
| 14th Order harmonic | A36 | A56 | A76 | % x 10 |
| 15th Order harmonic | A37 | A57 | A77 | % x 10 |
| 16th Order harmonic | A38 | A58 | A78 | % x 10 |
| 17th Order harmonic | A39 | A59 | A79 | % x 10 |
| 18th Order harmonic | A3A | A5A | A7A | % x 10 |
| 19th Order harmonic | A3B | A5B | A7B | % x 10 |
| 20th Order harmonic | A3C | A5C | A7C | % x 10 |
| 21st Order harmonic | A3D | A5D | A7D | % x 10 |
| 22nd Order harmonic | A3E | A5E | A7E | % x 10 |
| 23rd Order harmonic | A3F | A5F | A7F | % x 10 |
| 24th Order harmonic | A40 | A60 | A80 | % x 10 |
| 25th Order harmonic | A41 | A61 | A81 | % x 10 |
| 26th Order harmonic | A42 | A62 | A82 | % x 10 |
| 27th Order harmonic | A43 | A63 | A83 | % x 10 |
| 28th Order harmonic | A44 | A64 | A84 | % x 10 |
| 29th Order harmonic | A45 | A65 | A85 | % x 10 |
| 30th Order harmonic | A46 | A66 | A86 | % x 10 |

Table 21 (Continuation) : Modbus memory map (Table 3).

| Parameter | L1 Voltage | L2 Voltage | L3 Voltage | Units |
|---------------------|------------|------------|------------|--------|
| 31st Order harmonic | A47 | A67 | A87 | % x 10 |

Table 22: Modbus memory map (Table 4).

| Parameter | L1 Current | L2 Current | L3 Current | Units |
|---------------------|------------|------------|------------|--------|
| Fundamental Harm. | A88-A89 | AA8-AA9 | AC8-AC9 | mA |
| 2nd Order harmonic | A8A | AAA | AAC | % x 10 |
| 3rd Order harmonic | A8B | AAB | ACB | % x 10 |
| 4th Order harmonic | A8C | AAC | ADC | % x 10 |
| 5th Order harmonic | A8D | AAD | ACD | % x 10 |
| 6th Order harmonic | A8E | AAE | ACE | % x 10 |
| 7th Order harmonic | A8F | AAF | ACF | % x 10 |
| 8th Order harmonic | A90 | AB0 | AD0 | % x 10 |
| 9th Order harmonic | A91 | AB1 | AD1 | % x 10 |
| 10th Order harmonic | A92 | AB2 | AD2 | % x 10 |
| 11th Order harmonic | A93 | AB3 | AD3 | % x 10 |
| 12th Order harmonic | A94 | AB4 | AD4 | % x 10 |
| 13th Order harmonic | A95 | AB5 | AD5 | % x 10 |
| 14th Order harmonic | A96 | AB6 | AD6 | % x 10 |
| 15th Order harmonic | A97 | AB7 | AD7 | % x 10 |
| 16th Order harmonic | A98 | AB8 | AD8 | % x 10 |
| 17th Order harmonic | A99 | AB9 | AD9 | % x 10 |
| 18th Order harmonic | A9A | ABA | ADA | % x 10 |
| 19th Order harmonic | A9B | ABB | ADB | % x 10 |
| 20th Order harmonic | A9C | ABC | ADC | % x 10 |
| 21st Order harmonic | A9D | ABD | ADD | % x 10 |
| 22nd Order harmonic | A9E | ABE | ADE | % x 10 |
| 23rd Order harmonic | A9F | ABF | ADF | % x 10 |
| 24th Order harmonic | AA0 | AC0 | AE0 | % x 10 |
| 25th Order harmonic | AA1 | AC1 | AE1 | % x 10 |
| 26th Order harmonic | AA2 | AC2 | AE2 | % x 10 |
| 27th Order harmonic | AA3 | AC3 | AE3 | % x 10 |
| 28th Order harmonic | AA4 | AC4 | AE4 | % x 10 |
| 29th Order harmonic | AA5 | AC5 | AE4 | % x 10 |
| 30th Order harmonic | AA6 | AC6 | AE6 | % x 10 |
| 31st Order harmonic | AA7 | AC7 | AE7 | % x 10 |

4.10.3.4. Deleting parameters.

All the Modbus map addresses are hexadecimal.
The **0x05 function** is implemented for these variables.

Table 23: Modbus memory map: Deleting parameters.

| Parameters | Address | Valid data margin |
|--|---------|-------------------|
| Deleting energies | 834 | FF00 |
| Deleting maximum and minimum values | 838 | FF00 |
| Starting maximum demand | 839 | FF00 |
| Deleting the hour counters (All tariffs) | 83D | FF00 |
| Deleting the maximum value of the maximum demand | 83F | FF00 |
| Deleting energies, maximum demand and maximum and minimum values | 848 | FF00 |

4.10.3.5. Power status.

All the Modbus map addresses are hexadecimal.

The **0x04 function** is implemented for this variable.

This variable indicates the quadrant in which the device is operating.

Table 24: Modbus memory map: Power status

| Power status | | |
|--------------|---------|---------------|
| Variable | Address | Default value |
| Power status | 7D1 | - |

The variable format is shown in Table 25:

Table 25: Variable format: Power status.

| Bit 7 | Bit 6 | Bit 5 | Bit 4 | Bit 3 | Bit 2 | Bit 1 | Bit 0 |
|-------|-------|-------|-------|---------------|--------------|--------------|-------------|
| 0 | 0 | 0 | 0 | 1: Capacitive | 1: Inductive | 1: Generated | 1: Consumed |

4.10.3.6. The unit's serial number.

All the Modbus map addresses are hexadecimal.

The **0x04 function** is implemented for this variable.

Table 26: Modbus memory map: Serial number.

| The unit's serial number | | |
|--------------------------|-----------|---------------|
| Variable | Address | Default value |
| Serial number | 578 - 579 | - |

4.10.3.7. Detection of incorrect direction of rotation (Version 4.05 or higher)

All the Modbus map addresses are hexadecimal.

The **0x04 function** is implemented for this variable.

This variable indicates whether an incorrect direction of rotation has been detected in the voltages.

Table 27: Modbus memory map : Detection of incorrect direction of rotation.

| Detection of incorrect direction of rotation | | |
|--|---------|--|
| Variable | Address | Value |
| Detection of incorrect direction of rotation | 7D5 | 0: No fault has been detected 1: Fault detected |

4.10.3.8. Device configuration variables.

All the Modbus map addresses are hexadecimal.

The **0x04** and **0x10 functions** are implemented for this variable.

The device's Modbus function does not check whether the variables recorded are within the correct margins, they are only checked when they are read from the EEPROM. So if any parameter is recorded with an incorrect value the device will be configured with its default value.

The Modbus configuration will not take effect until the device is reset.

4.10.3.8.1. Transformation ratios.

Table 28: Modbus memory map: Transformation ratios.

| Transformation ratios | | | |
|---|-------------|-------------------------|---------------|
| Configuration variable ^{(3) (4)} | Address | Valid data margin | Default value |
| Voltage primary | 2710 - 2711 | 1 - 599999 | 1 |
| Voltage secondary | 2712 | 1 - 999 | 1 |
| Current primary | 2713 | 1 - 10000 | 5 |
| Current secondary | 2714 | 1: .../1A 5: .../5 A | 5 |

⁽³⁾ All variables must be programmed at the same time.

⁽⁴⁾ Voltage ratio x Current ratio < 600000.

Note: The ratio is between the primary and the secondary.

4.10.3.8.2. Neutral current transformation ratios (CVM-C10-ITF-IN and CVM-C10-MC-IN).

Table 29: Modbus memory map: Neutral current transformation ratios.

| Transformation ratios | | | |
|--|---------|-------------------------|---------------|
| Configuration variable ⁽⁵⁾ | Address | Valid data margin | Default value |
| Neutral current primary | 271A | 1 - 10000 | 5 |
| Neutral current secondary ⁽⁶⁾ | 271B | 1: .../1A 5: .../5 A | 5 |

⁽⁵⁾ All variables must be programmed at the same time.

⁽⁶⁾ This variable is only programmed for the **CVM-C10-ITF-IN** model.

4.10.3.8.3. Number of quadrants

Table 30: Modbus memory map: Number of quadrants

| Maximum demand | | | |
|------------------------|---------|----------------------------------|---------------|
| Configuration variable | Address | Valid data margin | Default value |
| Number of quadrants | 2B64 | 0: 4 quadrants 1: 2 quadrants | 0 |

4.10.3.8.4. Measurement convention

Table 31: Modbus memory map: Measurement convention.

| Measurement convention | | | |
|------------------------|---------|----------------------------------|---------------|
| Configuration variable | Address | Valid data margin | Default value |
| Measurement convention | 2B86 | 0: Circutor 1: IEC 2: IEEE | 0 |

4.10.3.8.5. Type of installation

Table 32: Modbus memory map: Type of installation

| Type of installation | | | |
|------------------------|---------|---|---------------|
| Configuration variable | Address | Valid data margin | Default value |
| Type of installation | 2B5C | 0: 4 - 3Ph Three-phase network with 4 wires. 1: 3 - 3Ph Three-phase network with 3 wires. 2: 3 - ArOn Three-phase network with 3 wires, Aron. 3: 3 - 2Ph Two-phase network with 3 wires. 4: 2 - 2Ph Single-phase network with 2 wires, phase-to-phase. 5: 2 - 1Ph Single-phase network with 2 wires, phase-to-neutral. | 0 |

4.10.3.8.6. Maximum demand

Table 33: Modbus memory map: Maximum demand

| Maximum demand | | | |
|------------------------|---------|-------------------|---------------|
| Configuration variable | Address | Valid data margin | Default value |
| Integration period | 274C | 1 - 60 minutes | 15 |

4.10.3.8.7. Operating profile

Table 34: Modbus memory map: Operating profile

| Operating profile | | | |
|------------------------|---------|---|---------------|
| Configuration variable | Address | Valid data margin | Default value |
| Operating profile | 2B60 | 0: Analyzer 1: User 2: Electrical energy efficiency, e ³ | 0 |

4.10.3.8.8. Display backlight

Table 35: Modbus memory map: Backlight

| Backlight | | | |
|------------------------|---------|---------------------------------|---------------|
| Configuration variable | Address | Valid data margin | Default value |
| Backlight | 2B5E | 0: Always lit 5 - 99 seconds | 0 |

4.10.3.8.9. Activating the harmonics display screen

Table 36: Modbus memory map: Display of harmonics

| Display of harmonics | | | |
|------------------------|---------|-------------------|---------------|
| Configuration variable | Address | Valid data margin | Default value |
| Display of harmonics | 2B62 | 0: No 1: Yes | 1 |

4.10.3.8.10. CO₂ consumption and generation emissions.

Table 37: Modbus memory map: CO₂ consumption and generation emissions.

| CO ₂ emissions | | | |
|--|---------|-------------------|---------------|
| Configuration variable ⁽⁷⁾⁽⁸⁾ | Address | Valid data margin | Default value |
| Tariff 1 consumption emissions ratio | 2724 | 0 - 1.9999 | 0 |
| Tariff 2 consumption emissions ratio | 2725 | 0 - 1.9999 | 0 |
| Tariff 3 consumption emissions ratio | 2726 | 0 - 1.9999 | 0 |
| Tariff 1 generation emissions ratio | 2728 | 0 - 1.9999 | 0 |
| Tariff 2 generation emissions ratio | 2729 | 0 - 1.9999 | 0 |
| Tariff 3 generation emissions ratio | 272A | 0 - 1.9999 | 0 |

⁽⁷⁾ All variables must be programmed at the same time.

⁽⁸⁾ They have 1 decimal place.

4.10.3.8.11. Cost of energy consumption and generation.

Table 38: Modbus memory map: Cost of energy consumption and generation.

| Cost per kWh | | | |
|---|---------|-------------------|---------------|
| Configuration variable ⁽⁹⁾⁽¹⁰⁾ | Address | Valid data margin | Default value |
| Cost per kWh of tariff 1 consumption | 272C | 0 - 1.9999 | 0 |
| Cost per kWh of tariff 2 consumption | 272D | 0 - 1.9999 | 0 |
| Cost per kWh of tariff 3 consumption | 272E | 0 - 1.9999 | 0 |
| Cost per kWh of tariff 1 generation | 2730 | 0 - 1.9999 | 0 |
| Cost per kWh of tariff 2 generation | 2731 | 0 - 1.9999 | 0 |
| Cost per kWh of tariff 3 generation | 2732 | 0 - 1.9999 | 0 |

⁽⁹⁾ All variables must be programmed at the same time.

⁽¹⁰⁾ They have 1 decimal place.

4.10.3.8.12. Programming alarms 1 and 2 (Relays 1 and 2)

Note: Configuration parameters not available for the CVM-C10-FLEX model.

Table 39: Modbus memory map: Programming alarms 1 and 2.

| Programming alarms 1 and 2 | | | | |
|----------------------------|-----------|-----------|---|---------------|
| Configuration variable | Address | | Valid data margin | Default value |
| | Relay 1 | Relay 2 | | |
| Maximum value. | 2AF8-2AF9 | 2B02-2B03 | depending on the variable | 0 |
| Minimum value | 2AFA-2AFB | 2B04-2B05 | depending on the variable | 0 |
| Variable code | 2AFC | 2B06 | Table 15 | 0 |
| Connection delay | 2AFD | 2B07 | 0 - 9999 seconds | 0 |
| Hysteresis: | 2AFE | 2B08 | 0 - 99 % | 0 |
| latch | 2AFF | 2B09 | 0 : No 1: Yes | 0 |
| Disconnection delay | 2B00 | 2B0A | 0 - 9999 seconds | 0 |
| Contacts status | 2B01 | 2B0B | 0 : Normally open 1: Normally closed | 0 |

4.10.3.8.13. Programming alarms 3 and 4 (Digital outputs T1 and T2)

Note: Configuration parameters not available for the *CVM-C10-FLEX*, *CVM-C10-ITF-IN* and *CVM-C10-MC-IN* models.

Table 40: Modbus memory map: Programming alarms 3 and 4.

| Programming alarms 3 and 4 | | | | |
|----------------------------|-----------|-----------|---------------------|---------------|
| Configuration variable | Address | | Valid data margin | Default value |
| | Relay 1 | Relay 2 | | |
| Kilowatts per impulse | 2B0C-2B0D | 2B16-2B17 | 0.001 - 999.999 kWh | 0 |
| Variable code | 2B10 | 2B1A | Table 18 | 0 |
| Pulse width | 2B11 | 2B1B | 10 - 500 ms | 100 ms |

4.10.3.8.14. Digital inputs

Table 41: Modbus memory map: Configuration of digital inputs.

| Configuration variable | Address | | Valid data margin | Default value |
|--------------------------------|---------|---------|-----------------------------|---------------|
| | Input 1 | Input 2 | | |
| Operating mode ⁽¹¹⁾ | 2B66 | 2B67 | 0: Tariff 1: Logic state | 0 |

⁽¹¹⁾ If Input 1 is configured as a tariff and Input 2 is configured as a logic state (or vice versa) we will only have 2 tariffs.

We can also read the status of the digital inputs when they are in logic mode:

The **0x04 function** is implemented for this variable.

Table 42: Modbus memory map: Status of the digital inputs (Logic state mode)

| Status of digital inputs | | |
|--------------------------|---------|---------------|
| Variable | Address | Default value |
| Status of digital inputs | 4E20 | - |

The variable format is shown in Table 43:

Table 43: Variable format: Status of digital inputs.

| Bit 7 | Bit 6 | Bit 5 | Bit 4 | Bit 3 | Bit 2 | Bit 1 | Bit 0 |
|-------|-------|-------|-------|-------|-------|----------------------------|----------------------------|
| 0 | 0 | 0 | 0 | 0 | 0 | Input 2 0: OFF 1: ON | Input 1 0: OFF 1: ON |

4.10.3.8.15. Digital outputs

Reading the status of the digital outputs.

The **0x04 function** is implemented for this variable.

Table 44: Modbus memory map: Status of the digital outputs

| Status of the digital outputs | | |
|-------------------------------|---------|---------------|
| Variable | Address | Default value |
| Status of the digital outputs | 4E21 | - |

The variable format is shown in Table 45:

Table 45: Variable format: Status of the digital outputs.

| Bit 7 | Bit 6 | Bit 5 | Bit 4 | Bit 3 | Bit 2 | Bit 1 | Bit 0 |
|-------|-------|-------|-------|-----------------------------|-----------------------------|-----------------------------|-----------------------------|
| 0 | 0 | 0 | 0 | Output 4 0: OFF 1: ON | Output 3 0: OFF 1: ON | Output 2 0: OFF 1: ON | Output 1 0: OFF 1: ON |

4.10.3.8.16. Communications

Table 46: Modbus memory map: Communications

| Communications | | | |
|---|------------|---|---------------|
| Configuration variable | Address | Valid data margin | Default value |
| Protocol | 2742 | 0 : Modbus 1: Bacnet | 0 |
| Modbus and BACnet: Peripheral number | 2743 | 0 - 255 | 1 |
| Modbus : Transmission speed | 2744 | 0: 9600 - 1:19200 | 0 |
| Modbus : Parity | 2745 | 0: No parity 1: Odd parity 2: Even parity | 0 |
| Modbus : Data bits | 2746 | 0 : 8 bits 1: 7 bits | 0 |
| Modbus : Stop bits | 2747 | 0 : 1 stop bit 1: 2 stop bits | 0 |
| BACnet: Device ID | 2EE0- 2EE1 | 0- 999999 | - |
| BACnet: MAC | 2EE2 | 0- 255 | 2 |

4.10.3.8.17. Password configuration

These variables allow you to lock or unlock access to the programming menu, and also allow you to change the password code. The password code may only be changed through this command. The device does not need you to enter the old password in order for it to record the new one; it records the new one directly without any verification.

Table 47: Modbus memory map: Password configuration

| Password | | | |
|--|---------|----------------------|---------------|
| Configuration variable ⁽¹²⁾ | Address | Valid data margin | Default value |
| Password value ⁽¹³⁾ | 2B70 | 0 - 9999 | 1234 |
| Lock-Unlock | 2B71 | 0: Unlock 1: Lock | 0 |

⁽¹²⁾ You must program all the variables at the same time.

⁽¹³⁾ The password value is read and written in hexadecimal.

4.10.4. BACnet PROTOCOL

BACnet is a communications protocol for Building Automation and Control NETWORKS. This protocol replaces the proprietary communications of each device, making it a set of common communication rules that enables the complete integration of the building automation and control devices of different manufacturers.

The device features **BACnet** MS/TP communications, following the specifications of ANSI/ASHRAE 135 (ISO 16484-5).

Using a RS485 connection, the device can connect to a BACnet and include all of the objects and services defined in the attached PICS map (Protocol Implementation Conformance Statement). ("**4.10.5. PICS MAP**")

The default speed is 9600 bps and the MAC is 2 (node number), and can be changed on the configuration screen or by entering the BaudRate and MAC_Address variables. The identifier (Device_ID) can be changed on the configuration screen using the writing property over the variable or through the Device_ID variable.

Another option is to overwrite the Object_Name in the Device object:

- a) #Baud x – where x can be: 9600, 19200
- b) #MAC x – where x can be: 0 ... 127
- c) #ID x – where x can be: 0 ... 999999

For further information on the protocol: www.bacnet.org.

4.10.5. MAPA PICS

PICS

Vendor Name: CIRCUTOR
Product Name: CVM-C10
Product Model Number: 0116
Application Software Version: 1.0
Firmware Revision: 0.7.1
BACnet Protocol Revision: 10

Product Description:

| |
|-------------------------|
| Electrical energy meter |
|-------------------------|

BACnet Standardized Device Profile (Annex L)

| | |
|---|--|
| x | BACnet Application Specific Controller (B-ASC) |
|---|--|

List all BACnet Interoperability Building supported (see Annex K in BACnet Addendum 135d):

| |
|--|
| DS-RP-B Read Property DS-WP-B Write Property DS-RPM-B Read Property Multiple DM-DDB-B Dynamic Device Binding DM-DOB-B Dynamic Object Binding DM-DCC-B Device Communication Control DM-RD-B Reinitialize Device |
|--|

Which of the following device binding methods does the product support? (check one or more)

| | |
|---|---|
| x | Recive Who-Is, send I-Am (BIBB DM-DDB-B) |
| x | Recive Who-Has, send I-Have (BIBB DM-DOB-B) |

Standard Object Types Supported:

Analog Input Object Type

| | | |
|---|----------------|----------------|
| 1. Dynamically creatable using BACnet's CreateObject service? | No | |
| 2. Dynamically deletable using BACnet's DeleteObject service? | No | |
| 3. List of optional properties supported: | max_pres_value | min_pres_value |
| 4. List of all properties that are writable where not otherw is a required by this standard | | |
| 5. List of proprietary properties: | | |
| 6. List of any property value range restrictions: | | |

Properly Identifier

| | |
|-------------|-------------------|
| Object_Name | max 32 characters |
|-------------|-------------------|

| DESCRIPTION | | SYMBOL | ID OBJECTS | OBJECT NAME | UNITS |
|---------------------|--------------------------|--------|------------|-------------|-------|
| Tensión fase-neutro | Voltage phase to neutral | V 1 | AI0 | Ph2NU1 | V |
| Corriente | Current | A 1 | AI1 | Ph1Current | A |
| Potencia activa | Active power | kW 1 | AI2 | ActPwrPh1 | kW |
| Potencia reactiva | Reactive power | kvar 1 | AI3 | ReactPwrPh1 | kvar |
| Factor de potencia | Power factor | PF 1 | AI4 | PwrFactPh1 | PF |
| Tensión fase-neutro | Voltage phase to neutral | V 2 | AI5 | Ph2NU2 | V |
| Corriente | Current | A 2 | AI6 | Ph2Current | A |
| Potencia activa | Active power | kW 2 | AI7 | ActPwrPh2 | kW |

| DESCRIPTION | | SYMBOL | ID OBJECTS | OBJECT NAME | UNITS |
|-------------------------------|--|-------------------|------------|----------------|---------------|
| Potencia reactiva | Reactive power | kvar 2 | AI8 | ReactPwrPh2 | kvar |
| Factor de potencia | Power factor | PF 2 | AI9 | PwrFactPh2 | PF |
| Tensión fase-neutro | Voltage phase to neutral | V 3 | AI10 | Ph2NU3 | V |
| Corriente | Current | A 3 | AI11 | Ph3Current | A |
| Potencia activa | Active power | kW 3 | AI12 | ActPwrPh3 | kW |
| Potencia reactiva | Reactive power | kvar 3 | AI13 | ReactPwrPh3 | kvar |
| Factor de potencia | Power factor | PF 3 | AI14 | PwrFactPh3 | PF |
| Potencia activa trifásica | Three phase active power | kW III | AI15 | ActPwOn3Ph | kW |
| Potencia inductiva trifásica | Three phase reactive inductive power | kvarL III | AI16 | InductPwOn3Ph | kvarL |
| Potencia capacitiva trifásica | Three phase capacitive inductive power | kvarC III | AI17 | CapPwOn3Ph | kvarC |
| Cos φ trifásico | Three phase cos φ | Cos φ III | AI18 | Cosphi | Cos φ |
| Factor de potencia trifásico | Three phase power factor | PFIll | AI19 | PwFactOn3Ph | PF |
| Frecuencia (L2) | Frequency | Hz | AI20 | Frequency | Hz |
| Tensión fase-fase | Voltage phase to phase | V12 | AI21 | Ph2PhU12 | V |
| Tensión fase-fase | Voltage phase to phase | V23 | AI22 | Ph2PhU23 | V |
| Tensión fase-fase | Voltage phase to phase | V31 | AI23 | Ph2PhU31 | V |
| %THD V | %THD V | %THD V1 | AI24 | THDVal_U1 | %THD |
| %THD V | %THD V | %THD V2 | AI25 | THDVal_U2 | %THD |
| %THD V | %THD V | %THD V3 | AI26 | THDVal_U3 | %THD |
| %THD A | %THD A | %THD A1 | AI27 | THDVal_I1 | %THD |
| %THD A | %THD A | %THD A2 | AI28 | THDVal_I2 | %THD |
| %THD A | %THD A | %THD A3 | AI29 | THDVal_I3 | %THD |
| Energía activa | Active energy | kW·h III | AI30 | ActEnergy | kW·h |
| Energía reactiva inductiva | Reactive inductive energy | kvarL·h III | AI31 | InductEnergy | kvarL·h |
| Energía reactiva capacitiva | Reactive capacitive energy | kvarC·h III | AI32 | CapEnergy | kvarC·h |
| Energía Aparente trifásica | Three phase aparent energy | kVA·h III | AI33 | AppEnergy | kVA·h |
| Energía activa generada | Three phase generated active energy | kW·h III (-) | AI34 | ActEnergy_exp | kW·h |
| Energía inductiva generada | Three phase generated reactive inductive energy | kvarL·h III (-) | AI35 | IndEnergy_exp | kvarL·h |
| Energía capacitiva generada | Three phase generated reactive capacitive energy | kvarC·h III(-) | AI36 | CapEnergy_exp | kvarC·h |
| Energía aparente generada | Three phase generated aparent energy | kVA·h III (-) | AI37 | AppEnergy_exp | kVA·h |
| Corriente trifásica (media) | Three phase average current | I_AVG | AI38 | AvgValCurr3Ph | I_AVG |
| Corriente de neutro | Neutral current | In | AI39 | NeutralCurrent | In |
| Potencia aparente L1 | Aparent power L1 | kVA | AI40 | AppPwrPh1 | kVA |
| Potencia aparente L2 | Aparent power L2 | kVA | AI41 | AppPwrPh2 | kVA |
| Potencia aparente L3 | Aparent power L3 | kVA | AI42 | AppPwrPh3 | kVA |
| Potencia aparente trifásica | Three phase aparent power | kVAIII | AI43 | AppPw3Ph | kVA |

| DESCRIPTION | | SYMBOL | ID OBJECTS | OBJECT NAME | UNITS |
|--------------------|--------------------|---------|------------|---------------|-------|
| Máxima demanda I1 | Maximum demand I1 | Md (A1) | AI44 | MaxDemand_A1 | A |
| Máxima demanda I2 | Maximum demand I2 | Md(A2) | AI45 | MaxDemand_A2 | A |
| Máxima demanda I3 | Maximum demand I3 | Md(A3) | AI46 | MaxDemand_A3 | A |
| Máxima demanda A | Maximum demand A | A III | AI47 | MaxDemand_A | A |
| Máxima demanda kW | Maximum demand kW | kW III | AI48 | MaxDemand_kW | kW |
| Máxima demanda kVA | Maximum demand kVA | kVA III | AI49 | MaxDemand_kVA | kVA |

Analog Value Object Type

| 1. Dynamically creatable using BACnet's CreateObject service? | | No |
|---|-------------------|-------------|
| 2. Dynamically deletable using BACnet's DeleteObject service? | | No |
| 3. List of optional properties supported: | | |
| 4. List of all properties that are writable where not otherwise required by this standard | | |
| 5. List of proprietary properties: | | |
| Property Identifier | Property Datatype | Meaning |
| 5. List of object identifiers and their meaning in this device | | |
| Object ID | Object Name | Description |
| AV1 | MAC_Address | MAC |
| AV2 | BaudRate | BAUD RATE |
| AV3 | Device_ID | DEVICE ID |

Device Object Type

| 1. Dynamically creatable using BACnet's CreateObject service? | | No |
|---|----------------------|--|
| 2. Dynamically deletable using BACnet's DeleteObject service? | | No |
| 3. List of optional properties supported: | | Description, Protocolo_Conformance_Class |
| 4. List of all properties that are writable where not otherwise required by this standard | | |
| Object_Name Max_Master Max_Info_Frames Object_Identifier | | |
| 5. List of proprietary properties: | | |
| 5. List of any property value range restrictions | | |
| Property Identifier | Restrictions | |
| Object_Name | < 32 bytes | |
| Object_Identifier | Device Type only | |
| Number_Of_APDU_Retries | 0-255 | |
| APDU_Timeout | 0-65535 milliseconds | |
| Vendor_Identifier | 0-65535 | |

Data Link Layer Options (check all that supported):

| | |
|---|--|
| X | MS/TP master (Clause 9), baud rate(s): 9.6, 19.2kB/s |
|---|--|

Character Sets Supported (check all that apply):

Indicating support for multiple character set does not imply that they can all be supported simultaneously.

| | |
|---|-----------|
| X | ANSI X3.4 |
|---|-----------|

5.- TECHNICAL FEATURES

| AC Power supply | |
|-----------------------|---------------------------|
| Rated voltage | 95 ... 240 V ~ $\pm 10\%$ |
| Frequency | 50 ... 60 Hz |
| Consumption | 4 ... 6 VA |
| Installation category | CAT III 300 V |

| DC Power supply | | |
|-----------------------|------------------------------|---|
| Rated voltage | 105 ... 272 V === $\pm 10\%$ | 23 ... 109 V === $\pm 10\%$ ⁽¹⁴⁾ |
| Consumption | 2 ... 6 W | 3.5 ... 3 W |
| Installation category | CAT III 300 V | |

⁽¹⁴⁾ Only available for references M5591100F0000, M5592100F0000, M5592100F0V00, M5594200F00000 and M5596100F0000.

| Voltage measurement circuit | |
|-----------------------------------|-------------------------|
| Rated voltage (Un) | 300 V Ph-N, 520 V Ph-Ph |
| Voltage measurement margin | 5 ... 120% Un |
| Frequency measurement margin | 45 ... 65Hz |
| Input impedance | 440 k Ω |
| Min. voltage measurement (Vstart) | 15 V |
| Installation category | CAT III 300 V |

| Current measurement circuit | | |
|-----------------------------------|-----------------------------------|---------------------------------------|
| CVM-C10-FLEX | Measure through Rogowski sensors. | |
| Nominal current (In) | CVM-C10-ITF CVM-C10-ITF-IN | CVM-C10-MC CVM-C10-MC-IN |
| | .../5A o .../1 A | .../0.250 A |
| | CVM-C10-mV | CVM-C10-FLEX |
| | .../0.333 V | .../100 mV ~ |
| Neutral current measurement | CVM-C10-ITF-IN | CVM-C10-FLEX |
| | .../5A o .../1 A | .../100 mV ~ |
| | CVM-C10-MC-IN | |
| | .../0.250 A | |
| Current measurement margin | CVM-C10-ITF CVM-C10-ITF-IN | CVM-C10-MC CVM-C10-MC-IN |
| | 2 ... 120% In | $\geq 10 \dots \leq 100\% \text{ In}$ |
| | CVM-C10-mV | CVM-C10-FLEX |
| | 2 ... 120% In | 0.2 ... 200% In |
| Maximum current, impulse < 1s | CVM-C10-ITF CVM-C10-ITF-IN | CVM-C10-MC CVM-C10-MC-IN |
| | 100 A | 100 A |
| | CVM-C10-mV | CVM-C10-FLEX |
| | 1.2 In | 2 In |
| Min. current measurement (Istart) | CVM-C10-ITF CVM-C10-ITF-IN | CVM-C10-MC CVM-C10-MC-IN |
| | 10 mA | 0.2 % In |
| | CVM-C10-mV | CVM-C10-FLEX |
| | 6.66 mV | 0.2 mV ~ |

| (Continuation) Current measurement circuit | | |
|--|-------------------------------|-----------------------------|
| Consumption | CVM-C10-ITF CVM-C10-ITF-IN | CVM-C10-MC CVM-C10-MC-IN |
| | 0.9 VA | 0.18 VA |
| | CVM-C10-mV | CVM-C10-FLEX |
| | 0.033 mVA | 0.004 VA |
| Installation category | | CAT III 300 V |

| Measurement accuracy (UNE-EN 61557-12) | | | |
|--|--|---|-----------------|
| Model | CVM-C10-ITF CVM-C10-ITF-IN | CVM-C10-MC ⁽¹⁷⁾ CVM-C10-MC-IN ⁽¹⁷⁾ | CVM-C10-mV |
| Voltage measurement | 0.5% ± 1 digit | 0.5% ± 1 digit | 0.5% ± 1 digit |
| Current measurement | 0.5% ± 1 digit | 0.5% ± 1 digit | 0.5% ± 1 digit |
| Frequency measurement | 0.5% | 0.5% | 0.5% |
| Active power measurement | 0.5% ± 2 digits | 1% ± 2 digits | 0.5% ± 2 digits |
| Reactive power measurement | 1% ± 2 digits | 2% ± 2 digits | 2% ± 2 digits |
| Active energy measurement | Class 0.5s ⁽¹⁵⁾ (I ≥ 0.1In) | Class 1 | Class 1 |
| Reactive energy measurement | Class 1 ⁽¹⁶⁾ (I ≥ 0.1In) | Class 2 | Class 2 |

⁽¹⁵⁾ According to IEC 62053-22.

⁽¹⁶⁾ According to IEC 62053-24.

⁽¹⁷⁾ Measurement range:

| | PF:1 | PF:0.5 |
|-------------------|------------------|------------------|
| Measurement range | ≥ 10% ... ≤ 100% | ≥ 20% ... ≤ 100% |

| Measurement accuracy (With sensors) (UNE-EN 61557-12) | |
|---|------------------------------|
| Model | CVM-C10-FLEX ⁽¹⁸⁾ |
| Voltage measurement | ± 0.5% + 1 decimal |
| Current measurement | ± 3% |
| Frequency measurement | ± 0.5% |
| Active power measurement | ± 4% |
| Reactive power measurement | ± 4% |

⁽¹⁸⁾ See section "3.3. - CVM-C10-FLEX: ROGOWSKI SENSORS"

| Pulse outputs (CVM-C10-ITF CVM-C10-MC and CVM-C10-mV) ⁽¹⁹⁾ | |
|---|--------------------------------|
| Quantity | 2 |
| Type | NPN outputs |
| Maximum voltage | 24 V === |
| Maximum current | 50 mA |
| Maximum frequency | 16 impulses / sec |
| Pulse width | 30 ms to 500 ms (Programmable) |

| Relay outputs (CVM-C10-ITF, CVM-C10-ITF-IN, CVM-C10-MC, CVM-C10-MC-IN, CVM-C10-mV) ⁽¹⁹⁾ | |
|--|---------------------------|
| Quantity | 2 |
| Max. voltage open contacts | 250 V ~ |
| Maximum current | 6 A |
| Maximum switching power | 1500 W (AC1) |
| Electrical life (250 VAC / 5A) | 60x10 ³ cycles |
| Mechanical life | 10x10 ⁶ cycles |

| Digital inputs ⁽¹⁹⁾ | |
|--------------------------------|----------------------------|
| Quantity | 2 |
| Type | NPN Potential free contact |
| Insulation | optoisolated |

⁽¹⁹⁾ Must be connected to SELV circuit.

| Communications | | |
|----------------|----------------------|---------|
| | Modbus RTU | BACnet |
| Bus | RS-485 | MS/TP |
| Protocol | Modbus RTU | BACnet |
| Baud rate | 9600 - 19200 | |
| Stop bits | 1 - 2 | 1 |
| Parity | without - even - odd | without |

| User interface | |
|----------------|--------------------|
| Display | LCD Custom COG |
| Keyboard | Capacitive, 3 keys |
| LED | 3 LED |

| Environmental features (CVM-C10-ITF and CVM-C10-ITF-IN) | |
|---|---|
| Operating temperature | -10°C ... +60°C |
| Storage temperature | -10°C ... +65°C |
| Relative humidity (non-condensing) | 5 ... 95% |
| Maximum altitude | 2000 m |
| Protection degree ⁽²⁰⁾ | IP21 Front panel: IP51 (IP64 with accessory) |

| Environmental features (CVM-C10-MC, CVM-C10-MC-IN, CVM-C10-mV and CVM-C10-FLEX) | |
|---|---|
| Operating temperature | -5°C ... +45°C |
| Storage temperature | -10°C ... +50°C |
| Relative humidity (non-condensing) | 5 ... 95% |
| Maximum altitude | 2000 m |
| Protection degree ⁽²⁰⁾ | IP21 Front panel: IP51 (IP64 with accessory) |

⁽²⁰⁾ This pollution degree hasn't been tested by UL.

| Mechanical features | |
|-------------------------|-------------------------------|
| Dimensions (Figure 35) | 96.7x96.7x62.5 mm |
| Weight | 330 gr |
| Surround | Self-extinguishing V0 plastic |
| Attachment | Panel |

| Standards | |
|--|-----------------------|
| Safety of electronic measuring units | UNE EN 61010: 2010 |
| Electromagnetic compatibility (CEM). Part 6-3: Generic standards. Emission standard for residential, commercial and light industry environments. | UNE EN 61000-6-3:2007 |
| Electromagnetic compatibility (CEM). Part 6-1: Generic standards. Immunity in residential, commercial and light industry environments | UNE EN 61000-6-1:2007 |
| Coordination of the insulation of units installed in low voltage systems (networks). | IEC 664:2007 |
| | VDE 0110 |
| Test for flammability of plastic materials for parts in devices and appliances | UL 94 |

| (Continuation) Standards | |
|--|------------------------------|
| Electromagnetic compatibility (EMC). Generic standards. Immunity for industrial environments | BS EN 61000-6-2 |
| Electromagnetic compatibility (EMC). Generic standards. Emission standard for industrial environments | BS EN 61000-6-4 |
| Safety requirements for electrical equipment for measurement, control, and laboratory use – Part 1: General requirements | UL / CSA 61010-1 3rd edition |




Figure 35: Dimensions of the CVM-C10.

6.- MAINTENANCE AND TECHNICAL SERVICE

In the case of any query in relation to device operation or malfunction, please contact the **CIRCUTOR SA** Technical Support Service.

Technical Assistance Service

Vial Sant Jordi, s/n, 08232 - Viladecavalls (Barcelona)

Tel: 902 449 459 (España) / +34 937 452 919 (outside of Spain)

email: sat@circutor.com

7.- GUARANTEE

CIRCUTOR guarantees its products against any manufacturing defect for two years after the delivery of the units.

CIRCUTOR will repair or replace any defective factory product returned during the guarantee period.



- No returns will be accepted and no unit will be repaired or replaced if it is not accompanied by a report indicating the defect detected or the reason for the return.
- The guarantee will be void if the units has been improperly used or the storage, installation and maintenance instructions listed in this manual have not been followed. "Improper usage" is defined as any operating or storage condition contrary to the national electrical code or that surpasses the limits indicated in the technical and environmental features of this manual.
- **CIRCUTOR** accepts no liability due to the possible damage to the unit or other parts of the installation, nor will it cover any possible sanctions derived from a possible failure, improper installation or "improper usage" of the unit. Consequently, this guarantee does not apply to failures occurring in the following cases:
 - Overvoltages and/or electrical disturbances in the supply;
 - Water, if the product does not have the appropriate IP classification;
 - Poor ventilation and/or excessive temperatures;
 - Improper installation and/or lack of maintenance;
 - Buyer repairs or modifications without the manufacturer's authorisation.

8.- CE CERTIFICATE



CIRCUITOR, SA – Vial Sant Jordi, s/n
08232 Viladecavalls (Barcelona) Spain
(+34) 937 452 900 – info@circuitor.com



DECLARACIÓN UE DE CONFORMIDAD

La presente declaración de conformidad se expide bajo la exclusiva responsabilidad de CIRCUITOR con dirección en Vial Sant Jordi, s/n – 08232 Viladecavalls (Barcelona) España

Producto:

Analizadores de redes panel 96 x96

Serie:

CVM-C10

Marca:

CIRCUITOR

EL objeto de la declaración es conforme con la legislación de armonización pertinente en la UE, siempre que sea instalado, mantenido y usado en la aplicación para la que ha sido fabricado, de acuerdo con las normas de instalación aplicables y las instrucciones del fabricante

2014/35/UE: Low Voltage Directive
2011/65/UE: RoHS2 Directive

Está en conformidad con la(s) siguiente(s) norma(s) u otro(s) documento(s) normativos(s):

IEC 61010-1:2010-AMD1:2016 CSV Ed 3.0 IEC 61326-1:2012 Ed 2.0
IEC 61000-6-2:2016 Ed 3.0 IEC 61000-6-4:2006-AMD1:2010 CSV Ed 2.1
UL 61010-1, 3rd Edition, 2012-5

Año de marcado "CE":

2014



EU DECLARATION OF CONFORMITY

This declaration of conformity is issued under the sole responsibility of CIRCUITOR with registered address at Vial Sant Jordi, s/n – 08232 Viladecavalls (Barcelona) Spain

Product:

Power analyzer mounting panel 96 x96

Series:

CVM-C10

Brand:

CIRCUITOR

The object of the declaration is in conformity with the relevant EU harmonisation legislation, provided that it is installed, maintained and used for the application for which it was manufactured, in accordance with the applicable installation standards and the manufacturer's instructions

2014/35/UE: Low Voltage Directive
2011/65/UE: RoHS2 Directive

It is in conformity with the following standard(s) or other regulatory document(s):

IEC 61010-1:2010-AMD1:2016 CSV Ed 3.0 IEC 61326-1:2012 Ed 2.0
IEC 61000-6-2:2016 Ed 3.0 IEC 61000-6-4:2006-AMD1:2010 CSV Ed 2.1
UL 61010-1, 3rd Edition, 2012-5

Year of CE mark:

2014



DECLARATION UE DE CONFORMITÉ

La présente déclaration de conformité est délivrée sous la responsabilité exclusive de CIRCUITOR dont l'adresse postale est Vial Sant Jordi, s/n – 08232 Viladecavalls (Barcelone) Espagne

Produit:

analyseurs de réseaux triphasés panneau 96x96

Série:

CVM-C10

Marque:

CIRCUITOR

L'objet de la déclaration est conforme à la législation d'harmonisation pertinente dans l'UE, à condition d'avoir été installé, entretenu et utilisé dans l'application pour laquelle il a été fabriqué, conformément aux normes d'installation applicables et aux instructions du fabricant

2014/35/UE: Low Voltage Directive
2011/65/UE: RoHS2 Directive

Il est en conformité avec la(les) suivante(s) norme(s) ou autre(s) document(s) réglementaire(s):

IEC 61010-1:2010-AMD1:2016 CSV Ed 3.0 IEC 61326-1:2012 Ed 2.0
IEC 61000-6-2:2016 Ed 3.0 IEC 61000-6-4:2006-AMD1:2010 CSV Ed 2.1
UL 61010-1, 3rd Edition, 2012-5

Année de marquage « CE »:

2014

Viladecavalls (Spain), 19/07/2017
General Manager: Ferran Gil Torné





KONFORMITÄTSERKLÄRUNG UE

Vorliegende Konformitätserklärung wird unter alleiniger Verantwortung von CIRCUTOR mit der Anschrift, Vial Sant Jordi, s/n – 08232 Viladecavalls (Barcelona) Spanien, ausgestellt

Producto:

Dreiphasen-Leistungsanalyser Schaltfrel 96 x96

Série:

CVM-C10

Marca:

CIRCUTOR

Der Gegenstand der Konformitätserklärung ist konform mit der geltenden Gesetzgebung zur Harmonisierung der EU, sofern die Installation, Wartung und Verwendung der Anwendung seinem Verwendungszweck entsprechend gemäß den geltenden Installationsstandards und der Vorgaben des Herstellers erfolgt.

2014/35/UE: Low Voltage Directive 2014/30/UE: Electromagnetic Compatibility Directive

2011/65/UE: RoHS2 Directive

Es besteht Konformität mit der/den folgenden Normen/Normen oder Regelwerk/Regelwerken

IEC 61010-1:2010-AMDI:2016 CSV Ed 3.0 IEC 61326-1:2012 Ed 2.0
IEC 61000-6-2:2016 Ed 3.0 IEC 61000-6-4:2006-AMDI:2010 CSV Ed 2.1
UL 61010-1, 3rd Edition, 2012-5

Jahr der CE-Kennzeichnung:

2014



DECLARAÇÃO DA UE DE CONFORMIDADE

A presente declaração de conformidade é expedida sob a exclusiva responsabilidade da CIRCUTOR com morada em Vial Sant Jordi, s/n – 08232 Viladecavalls (Barcelona) Espanha

Producto:

Analísadores de redes painel 96 x96

Série:

CVM-C10

Marca:

CIRCUTOR

O objeto da declaração está conforme a legislação de harmonização pertinente na UE, sempre que seja instalado, mantido e utilizado na aplicação para a qual foi fabricado, de acordo com as normas de instalação aplicáveis e as instruções do fabricante.

2014/35/UE: Low Voltage Directive 2014/30/UE: Electromagnetic Compatibility Directive

2011/65/UE: RoHS2 Directive

Está em conformidade com a(s) seguinte(s) norma(s) ou outro(s) documento(s) normativo(s):

IEC 61010-1:2010-AMDI:2016 CSV Ed 3.0 IEC 61326-1:2012 Ed 2.0
IEC 61000-6-2:2016 Ed 3.0 IEC 61000-6-4:2006-AMDI:2010 CSV Ed 2.1
UL 61010-1, 3rd Edition, 2012-5

Ano de marcação "CE":

2014



DICHIARAZIONE DI CONFORMITÀ UE

La presente dichiarazione di conformità viene rilasciata sotto la responsabilità esclusiva di CIRCUTOR, con sede in Vial Sant Jordi, s/n – 08232 Viladecavalls (Barcelona) Spagna

produto:

Analizzatori di reti pannello 96 x96

Serie:

CVM-C10

MARCHIO:

CIRCUTOR

L'oggetto della dichiarazione è conforme alla pertinente normativa di armonizzazione dell'Unione Europea, a condizione che venga installato, mantenuto e utilizzato nell'ambito dell'applicazione per cui è stato prodotto, secondo le norme di installazione applicabili e le istruzioni del produttore.

2014/35/UE: Low Voltage Directive 2014/30/UE: Electromagnetic Compatibility Directive

2011/65/UE: RoHS2 Directive

È conforme alle seguenti normative o altri documenti normativi:

IEC 61010-1:2010-AMDI:2016 CSV Ed 3.0 IEC 61326-1:2012 Ed 2.0
IEC 61000-6-2:2016 Ed 3.0 IEC 61000-6-4:2006-AMDI:2010 CSV Ed 2.1
UL 61010-1, 3rd Edition, 2012-5

Anno di marcatura "CE":

2014



[Signature]

Viladecavalls (Spain), 19/07/2017
General Manager: Ferran Gil Torné

CIRCUTOR, SA – Vial Sant Jordi, s/n
08232 Viladecavalls (Barcelona) Spain
(+34) 937 452 900 – info@circutor.com



DEKLARACJA ZGODNOŚCI UE

Niniejsza deklaracja zgodności zostaje wydana na wyłączną odpowiedzialność firmy CIRCUTOR z siedzibą pod adresem: Vial Sant Jordi, s/n – 08232 Viladecavalls (Barcelona) Hiszpania

produkt:

analyzer sieciowy tablicowy 96x96

Seria:

CVM-C10

marka:

CIRCUTOR

Przedmiot deklaracji jest zgodny z odnosnymi wymaganiami prawodawstwa harmonizacyjnego w Unii Europejskiej pod warunkiem, że będzie instalowany, konserwowany i użytkowany zgodnie z przeznaczeniem, dla którego został wyprodukowany, zgodnie z mającymi zastosowanie normami dotyczącymi instalacji oraz instrukcjami producenta

2014/35/UE: Low Voltage Directive 2014/30/UE: Electromagnetic Compatibility Directive
2011/65/UE: RoHS2 Directive

Jest zgodny z następującą(y)mi normą(ami) lub innym(i) dokumentem(ami) normatywnym(i):

IEC 61010-1:2010/AMD1:2016 CSV Ed 3.0 IEC 61326-1:2012 Ed 2.0
IEC 61000-6-2:2016 Ed 3.0 IEC 61000-6-4:2006/AMD1:2010 CSV Ed 2.1
UL 61010-1, 3rd Edition, 2012-5

Rok oznakowania "CE":

2014

Viladecavalls (Spain), 19/07/2017
General Manager: Ferran Gil Torné



CIRCUTOR, SA

Vial Sant Jordi, s/n

08232 - Viladecavalls (Barcelona)

Tel.: (+34) 93 745 29 00 - Fax: (+34) 93 745 29 14

www.circutor.com central@circutor.com